YAMAHA

PARTS CATALOGUE

YZF320-A (B7P1) EUROPE,SOUTH AFRICA
YZF320-A (B7P3) UNITED KINGDOM

YAMAHA GENUINE Parts & Accessories

1UB7P-300E1

( )

YZF320-A
PARTS CATALOGUE
©2018 by Yamaha Motor Co., Ltd.
1st edition, November 2018
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   “UR” Use specified parts number.

   “UN” Use as many as needed.

   “AP” Alternate Parts

   “LM” Locally Made (Parts need to be ordered locally)

   “F#” Frame No. (Applicable machine No.)

   “O/S” Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q’TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

PART NO.	DESCRIPTION	Q’TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



Frame Serial No.



8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
DPBM15	DEEP PURPLISH BLUE METALLIC 15	1329
DPBMC(*)	DEEP PURPLISH BLUE METALLIC C	0564
LGB	LOW GLOSS BLACK	0098
MBL2(*)	MAT BLACK 2	0582
SMX	BLACK METALLIC X	0903

MODEL LABEL

(1) A label called “Model Label” is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross–reference the “model code – production code No.” in the catalogue with the “model code – production code No.” indicated on the Model Label affixed onto the product concerned.

(2) “Model Label” Indication

a	b
○	xxxx – xxx
●	x c

a: Model Type Code
b: Production Code No.
c: Colouring Type

○	4TW1–010
●	A

(3) Model Label Affixing Location



(4) Colouring Information

Model Code	Colouring Type Code	Colour Code	Colour Name	Abbreviation
B7P1	A	0564	DEEP PURPLISH BLUE METALLIC C	DPBMC
	B	0582	MAT BLACK 2	MBL2
B7P3	A	0564	DEEP PURPLISH BLUE METALLIC C	DPBMC
	B	0582	MAT BLACK 2	MBL2

(5) Model Code – Production Code Number of Model Listed in This Parts Catalogue

Model Code	Production Code No.	Country (destination)
B7P1	010	AUSTRIA
		CZECHO
		FINLAND
		FRANCE
		GERMANY
		GUADELOPE
		HUNGARY
		ITALY
		MARTINIQUE, FRENCH W.I.
		SLOVAK
		SPAIN
		SWITZERLAND
	050	CROATIA
		CYPRUS
		GREECE
		IRELAND
		POLAND
		SLOVENIA
		SOUTH AFRICA
		TURKEY
B7P3	010	UNITED KINGDOM

Model Code	Production Code No.	Country (destination)

CONTENTS

ENGINE

CYLINDER HEAD....1
CRANKSHAFT & PISTON....3
VALVE....5
CAMSHAFT & CHAIN....6
WATER PUMP....7
RADIATOR & HOSE....8
OIL PUMP....9
INTAKE....10
EXHAUST....12
CRANKCASE....14
CRANKCASE COVER 1....15
STARTER CLUTCH....16
CLUTCH....17
TRANSMISSION....18
SHIFT CAM & FORK....20
SHIFT SHAFT....21

CHASSIS

FRAME....22
FENDER....24
SIDE COVER....26
REAR ARM & SUSPENSION....28
STEERING....29
FRONT FORK....30
FUEL TANK....32
SEAT....35
FRONT WHEEL....36
FRONT BRAKE CALIPER....37
REAR WHEEL....38
REAR BRAKE CALIPER....40
STEERING HANDLE & CABLE....41
FRONT MASTER CYLINDER....42
STAND & FOOTREST....44
REAR MASTER CYLINDER....46
WINDSHIELD....48
COWLING 1....50
GENERATOR....53
STARTING MOTOR....54
FLASHER LIGHT....55
METER....56
HEADLIGHT....57
TAILLIGHT....58
HANDLE SWITCH & LEVER....59
ELECTRICAL 1....60
ELECTRICAL 2....62
ELECTRICAL 3....64

INDEX

NUMERICAL INDEX....65

FIG. 1 CYLINDER HEAD



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BR5–E1102–10	CYLINDER HEAD ASSY	1	1				
2	2MS–E1133–10	.GUIDE, VALVE 1	4	4				
3	1WD–E1133–10	.GUIDE, VALVE 1	4	4				
4	90105–06027	.BOLT, FLANGE	12	12				
5	90340–18002	.PLUG, STRAIGHT SCREW	1	1				
6	95022–08012	BOLT, FLANGE	1	1				
7	90430–08119	GASKET	1	1				
8	95612–08625	BOLT, STUD	4	4				
9	2MS–11361–00	BOLT, CYLINDER HOLDING 1	6	6				
10	90201–10845	WASHER, PLATE	6	6				
11	90110–06870	BOLT, HEXAGON SOCKET HEAD	2	2				
12	94700–00436	PLUG, SPARK (NGK LMAR8A-9)	2	2				
13	BR5–E1181–00	GASKET, CYLINDER HEAD 1	1	1				
14	99530–14016	PIN, DOWEL	2	2				
15	90109–06898	BOLT	1	1				
16	1WD–E111G–00	RUBBER, MOUNT 1	1	1				
17	1WD–E1191–00	COVER, CYLINDER HEAD 1	1	1				
18	1WD–E2241–00	GUIDE, STOPPER 2	1	1				
19	1WD–E1193–00	GASKET, HEAD COVER 1	1	1				
20	5VY–1482K–00	PLATE	2	2				
21	1WD–E4890–00	REED VALVE ASSY	1	1				
22	1WD–E4899–00	CAP, CASE	1	1				
23	91332–06020	BOLT	2	2				
24	90109–06899	BOLT	4	4				
25	1WD–E111G–00	RUBBER, MOUNT 1	4	4				
26	2MS–E1311–10	CYLINDER 1	1	1				
27	1WD–E1351–00	GASKET, CYLINDER	1	1				



FIG. 1 CYLINDER HEAD

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	5NL–12564–00	PIPE, WATER	1	1				
29	93210–16716	O-RING	1	1				
30	99530–14016	PIN, DOWEL	2	2				
31	1WD–E4840–00	AIR CUT VALVE ASSY	1	1				
32	1WD–E4881–00	HOSE, BEND 1	1	1				
33	90467–16801	CLIP	2	2				
34	1WD–E4882–01	HOSE, BEND 2	1	1				
35	90467–16801	CLIP	1	1				
36	90467–16800	CLIP	1	1				

FIG. 2 CRANKSHAFT & PISTON



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E1411–00	CRANKSHAFT	1	1				UR
	1WD–11411–00	CRANKSHAFT	1	1				UR
2	1WD–11650–00	CONNECTING ROD ASSY	2	2				
3	5SL–11654–00	.BOLT, CONNECTING ROD	2	2				
4	90179–07652	.NUT	2	2				
5	1WD–11656–00	PLANE BEARING, CONNECTING ROD	4	4				UR BLUE
	1WD–11656–10	PLANE BEARING, CONNECTING ROD	4	4				UR BLACK
	1WD–11656–20	PLANE BEARING, CONNECTING ROD	4	4				UR BROWN
	1WD–11656–30	PLANE BEARING, CONNECTING ROD	4	4				UR GREEN
6	1WD–E1536–00	GEAR, DRIVE	1	1				
7	1WD–E1549–00	SPROCKET, CAM CHAIN	1	1				
8	90105–10883	BOLT, FLANGE	1	1				
9	90201–10848	WASHER, PLATE	1	1				
10	1WD–11416–00	PLANE BEARING, CRANKSHAFT 1	6	6				UR BLUE
	1WD–11416–10	PLANE BEARING, CRANKSHAFT 1	6	6				UR BLACK
	1WD–11416–20	PLANE BEARING, CRANKSHAFT 1	6	6				UR BROWN
	1WD–11416–30	PLANE BEARING, CRANKSHAFT 1	6	6				UR GREEN
	1WD–11416–40	PLANE BEARING, CRANKSHAFT 1	6	6				UR YELLOW
11	BR5–E1631–00	PISTON (STD)	2	2				
12	BR5–E1603–00	PISTON RING SET (STD)	2	2				
13	1WD–E1633–00	PIN, PISTON	2	2				
14	93450–16068	CIRCLIP	4	4				
15	1WD–E1531–00	GEAR, BALANCE WEIGHT	1	1				
16	90105–088F8	BOLT, FLANGE	1	1				
17	90282–04036	KEY, STRAIGHT	1	1				
18	1WD–E1496–00	BOSS, BUFFER	1	1				
19	90201–16812	WASHER, PLATE	1	1				



FIG. 2 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
20	90501–22800	SPRING, COMPRESSION	4	4				
21	93605–10090	PIN, DOWEL	2	2				
22	1WD–E1454–00	WEIGHT 1	1	1				
23	1WD–11413–00	METAL, BALANCE WEIGHT	4	4				UR BLUE
	1WD–11413–10	METAL, BALANCE WEIGHT	4	4				UR BLACK
	1WD–11413–20	METAL, BALANCE WEIGHT	4	4				UR BROWN
	1WD–11413–30	METAL, BALANCE WEIGHT	4	4				UR GREEN
	1WD–11413–40	METAL, BALANCE WEIGHT	4	4				UR YELLOW

FIG. 3 VALVE



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2MS–E2111–00	VALVE, INTAKE	4	4				
2	2MS–E2121–00	VALVE, EXHAUST	4	4				
3	2MS–E2126–00	SEAT, VALVE SPRING 2	8	8				
4	BR5–E2113–00	SPRING, VALVE INNER	8	8				
5	2MS–E2117–00	RETAINER, VALVE SPRING	8	8				
6	3S0–E2118–00	LOCK, VALVE SPRING RETAINER	16	16				
7	1PA–E2119–00	SEAL, VALVE STEM	8	8				
8	1HX–12168–F0	PAD, ADJUSTING 2 (1.50)	8	8				UR
	1HX–12168–H1	PAD, ADJUSTING 2 (1.55)	8	8				UR
	1HX–12168–K1	PAD, ADJUSTING 2 (1.60)	8	8				UR
	1HX–12168–M1	PAD, ADJUSTING 2 (1.65)	8	8				UR
	1HX–12168–R1	PAD, ADJUSTING 2 (1.70)	8	8				UR
	1HX–12168–U1	PAD, ADJUSTING 2 (1.75)	8	8				UR
	1HX–12168–W1	PAD, ADJUSTING 2 (1.80)	8	8				UR
	1HX–12168–Y1	PAD, ADJUSTING 2 (1.85)	8	8				UR
	1HX–12169–11	PAD, ADJUSTING 2 (1.90)	8	8				UR
	1HX–12169–31	PAD, ADJUSTING 2 (1.95)	8	8				UR
	1HX–12169–50	PAD, ADJUSTING 2 (2.00)	8	8				UR
	1HX–12169–70	PAD, ADJUSTING 2 (2.05)	8	8				UR
	1HX–12169–90	PAD, ADJUSTING 2 (2.10)	8	8				UR
	1HX–12169–E0	PAD, ADJUSTING 2 (2.15)	8	8				UR
	1HX–12169–G0	PAD, ADJUSTING 2 (2.20)	8	8				UR
	1HX–12169–J0	PAD, ADJUSTING 2 (2.25)	8	8				UR
	1HX–12169–L0	PAD, ADJUSTING 2 (2.30)	8	8				UR
	1HX–12169–N0	PAD, ADJUSTING 2 (2.35)	8	8				UR
	1HX–12169–T0	PAD, ADJUSTING 2 (2.40)	8	8				UR
9	2MS–E2153–11	LIFTER, VALVE	8	8				

FIG. 4 CAMSHAFT & CHAIN



1WD1460-P040

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BR5–E2170–00	CAMSHAFT ASSY 1	1	1				
2	BR5–E2180–00	CAMSHAFT ASSY 2	1	1				
3	1WD–E2176–00	SPROCKET, CAM CHAIN	2	2				
4	90105–07800	BOLT, FLANGE	4	4				
5	94568–K0118	CHAIN (98XRH2015-118P-M)	1	1				
6	2MS–12210–00	TENSIONER ASSY, CAM CHAIN	1	1				
7	95022–06008	BOLT, FLANGE	1	1				
8	90430–06014	GASKET	1	1				
9	1WD–E2213–00	GASKET, TENSIONER CASE	1	1				
10	91332–06020	BOLT	2	2				
11	1WD–E2251–00	DAMPER, CHAIN 1	1	1				
12	2MS–E2252–01	DAMPER, CHAIN 2	1	1				
13	90110–06161	BOLT, HEXAGON SOCKET HEAD	2	2				
14	1WD–E2256–00	COVER, CHAIN	1	1				
15	90110–06161	BOLT, HEXAGON SOCKET HEAD	2	2				

FIG. 5 WATER PUMP



1WD1460-P050

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E2420–00	WATER PUMP ASSY	1	1				
2	1WD–E5421–00	.COVER, CRANKCASE 2	1	1				
3	93317–11096	.BEARING	1	1				
4	93315–21570	.BEARING	1	1				
5	93102–15801	.OIL SEAL	1	1				
6	1WD–E2450–00	.IMPELLER SHAFT ASSY	1	1				
7	1WD–E2453–00	.GEAR	1	1				
8	33S–E2223–00	.SEAL	1	1				
9	33S–E2456–00	.WASHER	2	2				
10	1WD–E319L–00	.PIN, STRAIGHT	1	1				
11	99009–08400	.CIRCLIP	1	1				
12	1WD–E2681–00	.PLATE	1	1				
13	91312–06010	.BOLT, HEXAGON SOCKET HEAD	2	2				
14	1WD–E2422–00	.COVER, HOUSING	1	1				
15	1WD–E2428–00	.GASKET, HOUSING COVER 2	1	1				
16	90430–06014	.GASKET	1	1				
17	95022–06025	.BOLT, FLANGE	3	3				
18	2H7–15361–00	GAUGE, LEVEL	1	1				
19	1WD–E5362–00	PLUG, OIL LEVEL	1	1				
20	93210–27807	O-RING	1	1				



1WD1460-P060

FIG. 6 RADIATOR & HOSE

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	5P0–12411–00	THERMOSTAT	1	1				
2	1WD–E2413–00	COVER, THERMOSTAT	1	1				
3	95022–06020	BOLT, FLANGE	2	2				
4	1WD–E2577–00	HOSE 2	1	1				
5	1WD–E2578–00	HOSE 3	1	1				
6	90467–250A1	CLIP	2	2				
7	90450–28001	HOSE CLAMP ASSY	2	2				
8	1WD–E2461–00	RADIATOR COMP	1	1				
9	2MS–E2405–00	BLOWER ASSY	1	1				
10	1WD–E2671–00	NUT 1	5	5				
11	5YP–E2675–00	BOLT, BLOWER HOLDING	3	3				
12	5ST–E2462–00	CAP, RADIATOR	1	1				
13	95827–06025	BOLT, FLANGE	2	2				
14	90201–06072	WASHER, PLATE	2	2				
15	90387–064W3	COLLAR	2	2				
16	90480–15808	GROMMET	3	3				



FIG. 7 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E3300–01	OIL PUMP ASSY	1	1				
2	99009–15500	.CIRCLIP	1	1				
3	1WD–E3341–00	GEAR, OIL PUMP IDLE	1	1				
4	1WD–E3342–00	SHAFT, IDLE GEAR	1	1				
5	99009–10400	CIRCLIP	2	2				
6	90201–10119	WASHER, PLATE	1	1				
7	99530–08012	PIN, DOWEL	2	2				
8	91332–06030	BOLT	4	4				
9	1WD–E3410–00	STRAINER HOUSING ASSY	1	1				
10	1WD–E3415–00	SEAL, OIL STRAINER	1	1				
11	1WD–E3440–10	ELEMENT ASSY, OIL CLEANER	1	1				
12	90401–20008	BOLT, UNION	1	1				
13	1WD–E3417–00	COVER, STRAINER	1	1				
14	90340–12808	PLUG, STRAIGHT SCREW	1	1				
15	4YS–E1198–00	GASKET	1	1				
16	1WD–E3414–00	GASKET, STRAINER COVER	1	1				
17	95022–06025	BOLT, FLANGE	11	11				
18	90462–08810	CLAMP	1	1				



FIG. 8 INTAKE

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2MS–E3586–00	JOINT, CARBURETOR 1	1	1				
2	93210–39802	O-RING	2	2				
3	91332–06016	BOLT	3	3				
4	90450–55804	HOSE CLAMP ASSY	2	2				
5	BR5–E3750–01	THROTTLE BODY ASSY	1	1				
6	1WD–E3761–00	.INJECTOR	2	2				
7	5PS–14147–00	..O-RING	1	1				
8	1WD–E3556–00	.GASKET, MANIFOLD	2	2				
9	98502–06012	.SCREW, PAN HEAD	1	1				
10	1WD–E4243–00	.PLATE	1	1				
11	1WS–85801–00	.STEPPING MOTOR	1	1				
12	1WD–E3938–00	.PIPE	1	1				
13	1WD–E3573–00	.BOLT 1	2	2				
14	8GL–13571–00	.WASHER	2	2				
15	8HG–14534–00	.COLLAR	2	2				
16	1WS–14335–00	.SPRING, PLUNGER	1	1				
17	895–14169–00	.CAP	2	2				
18	8A7–14139–00	.CLIP, PIPE	2	2				
19	54P–E416A–00	..O-RING	1	1				
20	5JW–14104–00	.AIR SCREW SET	2	2				
21	2MS–E4465–00	PIPE	1	1				
22	2MS–E4466–00	PIPE	1	1				
23	90413–06031	WAY 3	1	1				
24	90467–090A2	CLIP	4	4				
25	BR5–E4411–00	CASE, AIR CLEANER 1	1	1				
26	2MS–E4469–00	FUNNEL, AIR	1	1				
27	2MS–E446C–00	FUNNEL 2	1	1				



FIG. 8 INTAKE

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	BR5–E4437–00	DUCT	1	1				
29	BR5–E4412–00	CAP, CLEANER CASE 1	1	1				
30	1WD–E4452–00	SEAL	1	1				
31	1WD–E4457–00	SEAL	1	1				
32	97702–50025	SCREW, TAPPING	8	8				
33	1WD–E4422–00	CAP, CLEANER CASE 2	1	1				
34	1WD–E4462–00	SEAL	1	1				
35	98902–05020	SCREW, BIND	3	3				
36	1WD–E4451–00	ELEMENT, AIR CLEANER	1	1				
37	52B–E443E–00	PIPE, DRAIN	1	1				
38	90467–110A3	CLIP	1	1				
39	54P–E3474–00	BAND	2	2				
40	95D32–06010	BOLT, FLANGE DEEP RECESS	2	2				
41	BR5–E3543–00	HOSE, AIR	1	1				
42	90467–13802	CLIP	1	1				
43	90467–12052	CLIP	1	1				
44	2MS–E5373–01	PIPE, BREATHER	1	1				
45	90467–13802	CLIP	2	2				

FIG. 9 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2MS–E4602–00	EXHAUST PIPE COMP.	1	1				
2	1WD–E473L–00	BRACKET 3	1	1				
3	95027–06010	BOLT, FLANGE	2	2				
4	5TP–E4747–00	DAMPER, MUFFLER	1	1				
5	1WD–E4775–00	NUT	1	1				
6	BR5–E4710–00	MUFFLER ASSY 1	1	1				
7	1WD–E4758–00	.PROTECTOR, SILENCER	1	1				
8	90111–06802	.BOLT,HEX. SOCKET BUTTON	2	2				
9	90183–06818	.NUT, SPRING	1	1				
10	1WD–E4728–00	.PROTECTOR, MUFFLER 2	1	1				
11	90480–12581	.GROMMET	1	1				
12	90387–087L0	.COLLAR	1	1				
13	90111–06847	.BOLT,HEX. SOCKET BUTTON	1	1				
14	1WD–E4763–00	.SPACER	1	1				
15	54D–E4714–00	.GASKET, MUFFLER	1	1				
16	1WD–E4715–00	.BAND, MUFFLER	1	1				
17	95027–08035	.BOLT, FLANGE	1	1				
18	90387–068N4	.COLLAR	1	1				
19	90201–06088	.WASHER, PLATE	1	1				
20	90183–06011	.NUT, SPRING	1	1				
21	1WD–E4613–00	GASKET, EXHAUST PIPE	2	2				
22	95707–08500	NUT, FLANGE	4	4				
23	90105–088G7	BOLT, FLANGE	2	2				
24	90201–08612	WASHER, PLATE	2	2				
25	95817–08030	BOLT, FLANGE	1	1				
26	90201–087F0	WASHER, PLATE	1	1				
27	1WD–E4628–00	PROTECTOR, EXHAUST PIPE	1	1				

FIG. 9 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	90480–12581	GROMMET	3	3				
29	90387–087L0	COLLAR	3	3				
30	90111–06152	BOLT,HEX. SOCKET BUTTON	3	3				
31	95607–08200	NUT, SELF-LOCKING	1	1				

FIG. 10 CRANKCASE



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E5150–20	CRANKCASE ASSY	1	1				
2	90338–16262	PLUG	2	2				
3	93210–12803	O-RING	2	2				
4	1WD–E5148–00	NOZZLE 2	1	1				
5	99530–10014	PIN, DOWEL	2	2				
6	90105–088F7	BOLT, FLANGE	6	6				
7	90105–088G0	BOLT, FLANGE	2	2				
8	95812–06035	BOLT, FLANGE	2	2				
9	95812–06045	BOLT, FLANGE	6	6				
10	95812–06065	BOLT, FLANGE	5	5				
11	90110–06882	BOLT, HEXAGON SOCKET HEAD	1	1				
12	90430–06014	GASKET	4	4				
13	1WD–E5155–00	NOZZLE 3	1	1				
14	93210–068F7	O-RING	1	1				



FIG. 11 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E5411–00	COVER, CRANKCASE 1	1	1				
2	91312–05012	BOLT, HEXAGON SOCKET HEAD	2	2				
3	92014–08012	BOLT, BUTTON HEAD	1	1				
4	90430–08143	GASKET	1	1				
5	90340–32819	PLUG, STRAIGHT SCREW	1	1				
6	93210–32816	O-RING	1	1				
7	1WD–E5451–00	GASKET, CRANKCASE COVER 1	1	1				
8	99530–08012	PIN, DOWEL	2	2				
9	95022–06025	BOLT, FLANGE	9	9				
10	1WD–E5461–00	GASKET, CRANKCASE COVER 2	1	1				
11	99530–08012	PIN, DOWEL	2	2				
12	95022–06025	BOLT, FLANGE	9	9				
13	95022–06050	BOLT, FLANGE	1	1				
14	2MS–E5441–00	HOLDER, CLUTCH CABLE	1	1				
15	91312–06025	BOLT, HEXAGON SOCKET HEAD	2	2				
16	1WD–E5413–10	COVER	1	1				
17	1WD–E5462–00	GASKET, CRANKCASE COVER 3	1	1				
18	95022–06025	BOLT, FLANGE	8	8				
19	90462–08812	CLAMP	1	1				
20	90462–08806	CLAMP	1	1				
21	1WD–E5377–00	GUIDE, INLET	1	1				
22	1WD–E5418–00	COVER, CHAIN CASE	1	1				
23	95022–06025	BOLT, FLANGE	2	2				
24	90462–08225	CLAMP	2	2				

FIG. 12 STARTER CLUTCH



1WD1460-P120

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E5514–00	GEAR 2	1	1				
2	44D–E5521–00	SHAFT 1	1	1				
3	1WD–E5515–10	GEAR 3	1	1				
4	1WD–E5580–00	STARTER CLUTCH OUTER ASSY	1	1				
5	90110–06161	BOLT, HEXAGON SOCKET HEAD	3	3				

FIG. 13 CLUTCH



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E6111–00	GEAR, PRIMARY DRIVE	1	1				
2	2MS–E6150–00	PRIMARY DRIVEN GEAR COMP.	1	1				
3	1WD–E6154–00	PLATE, THRUST 1	1	1				
4	2MS–E6371–00	BOSS, CLUTCH	1	1				
5	1WD–E6331–00	PLATE, FRICTION 2	7	7				
6	1WD–E6324–00	PLATE, CLUTCH 1	6	6				
7	2MS–E6350–01	PRESSURE PLATE ASSY	1	1				
8	2MS–E6333–10	SPRING, CLUTCH 1	4	4				
9	1WD–E6337–00	SCREW, SPRING	4	4				
10	90215–18800	WASHER, LOCK	1	1				
11	90170–18221	NUT	1	1				
12	90201–22013	WASHER, PLATE	1	1				
13	1WD–E6181–00	SPACER 1	1	1				
14	1WD–E6356–00	ROD, PUSH 1	1	1				
15	2MS–E6340–00	PUSH LEVER ASSY	1	1				
16	90201–10843	WASHER, PLATE	1	1				
17	99009–10400	CIRCLIP	1	1				
18	90508–18136	SPRING, TORSION	1	1				
19	1WD–16382–00	AXLE, PUSH LEVER	1	1				
20	92902–08600	WASHER, PLATE	1	1				
21	99002–07600	CIRCLIP(E)	1	1				

FIG. 14 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2MS–E7411–00	AXLE, MAIN (14T)	1	1				
2	2MS–E7151–00	GEAR, 5TH PINION (25T)	1	1				
3	90214–22008	WASHER, CLAW	1	1				
4	93440–24200	CIRCLIP	1	1				
5	2MS–E7131–00	GEAR, 3RD PINION (23T/23T)	1	1				
6	2MS–E7161–00	GEAR, 6TH PINION (30T)	1	1				
7	2MS–E7121–00	GEAR, 2ND PINION (17T)	1	1				
8	93306–255Y9	BEARING	1	1				
9	93440–52009	CIRCLIP	1	1				
10	93311–420Y3	BEARING	1	1				
11	93101–20802	OIL SEAL	1	1				
12	278–17425–00	CIRCLIP 2	1	1				
13	1WD–E7402–00	DRIVE AXLE ASSY	1	1				
14	2MS–E7221–00	GEAR, 2ND WHEEL (31T)	1	1				
15	90209–25011	WASHER	1	1				
16	93440–28184	CIRCLIP	1	1				
17	2MS–E7261–00	GEAR, 6TH WHEEL (24T)	1	1				
18	2MS–E7231–00	GEAR, 3RD WHEEL (31T)	1	1				
19	2MS–E7241–00	GEAR, 4TH WHEEL (25T)	1	1				
20	90214–22008	WASHER, CLAW	1	1				
21	93440–24200	CIRCLIP	1	1				
22	2MS–E7251–00	GEAR, 5TH WHEEL (23T)	1	1				
23	2MS–E7211–00	GEAR, 1ST WHEEL (35T)	1	1				
24	90387–20814	COLLAR	1	1				
25	90201–20276	WASHER, PLATE (T=1.0)	2	2				
26	93311–420Y3	BEARING	1	1				
27	93101–20802	OIL SEAL	1	1				



FIG. 14 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	1WD–17424–00	CIRCLIP 1	1	1				
29	278–17425–00	CIRCLIP 2	1	1				
30	93102–35803	OIL SEAL	1	1				
31	1WD–E7460–00	SPROCKET, DRIVE (14T)	1	1				
32	90201–20023	WASHER, PLATE	1	1				
33	90179–20013	NUT	1	1				

FIG. 15 SHIFT CAM & FORK



1WD1460-P150

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E8540–10	SHIFT CAM ASSY	1	1				
2	5TP–E8542–00	POINT, NEUTRAL	1	1				
3	90501–06022	SPRING, COMPRESSION	1	1				
4	1WD–E8511–00	FORK, SHIFT 1	1	1				
5	1WD–E8512–00	FORK, SHIFT 2	1	1				
6	1WD–E8513–00	FORK, SHIFT 3	1	1				
7	1WD–E8531–00	BAR, SHIFT FORK GUIDE 1	2	2				
8	90501–080A2	SPRING, COMPRESSION	4	4				
9	1WD–E8536–00	STOPPER, SHIFT BAR	1	1				
10	1WD–E8562–00	PLATE, STOPPER 2	1	1				
11	90110–06182	BOLT, HEXAGON SOCKET HEAD	2	2				

FIG. 16 SHIFT SHAFT



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–E8337–00	SPRING	1	1				
2	1WD–E8127–10	STOPPER, SCREW	1	1				
3	1WD–E8175–00	SPACER	1	1				
4	1WD–E8101–00	SHIFT SHAFT ASSY	1	1				
5	90508–29806	.SPRING, TORSION	1	1				
6	99009–12400	.CIRCLIP	2	2				
7	90201–127E1	WASHER, PLATE	1	1				
8	1WD–E8140–00	STOPPER LEVER ASSY	1	1				
9	93317–11295	BEARING	1	1				
10	93102–12891	OIL SEAL	1	1				
11	1WD–E8110–00	SHIFT PEDAL ASSY	1	1				
12	1WD–E8111–00	.PEDAL, SHIFT	1	1				
13	1EG–E8113–01	.COVER, SHIFT PEDAL	1	1				
14	1WD–E8115–00	.ROD, SHIFT	1	1				
15	90170–06023	.NUT	1	1				
16	95302–06600	.NUT, HEXAGON	1	1				
17	1WD–E8112–00	.ARM, SHIFT	1	1				
18	BS8–F7261–00	SHAFT	1	1				
19	90206–14001	WASHER, WAVE	1	1				
20	90201–10021	WASHER, PLATE	1	1				
21	97012–06020	BOLT	1	1				



FIG. 17 FRAME

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F1110–12	FRAME COMP.	1	1				
2	1WD–F112C–00	DAMPER 2	2	2				
3	1WD–F117G–00	PROTECTOR	2	2				
4	1WD–F1652–00	PROTECTOR	1	1				
5	1WD–F193A–00	PROTECTOR	2	2				
6	5D9–F414G–00	SEAL	1	1				
7	90388–10816	DAMPER	2	2				
8	1WD–F191B–00	PLATE 1	2	2				
9	91317–10060	BOLT,HEX.SOCKET HEAD	2	2				
10	92902–10200	WASHER	2	2				
11	90105–10889	BOLT, FLANGE	1	1				
12	90105–10891	BOLT, FLANGE	1	1				
13	90179–10805	NUT	2	2				
14	1WD–F135F–00	COVER	2	2				
15	90338–23801	PLUG	2	2				
16	1WD–F1171–00	BOX	1	1				
17	90480–13398	GROMMET	1	1				
18	90387–07819	COLLAR	2	2				
19	95022–06014	BOLT, FLANGE	2	2				
20	90183–06818	NUT, SPRING	2	2				
21	90464–30009	CLAMP	1	1				
22	90464–12015	CLAMP	1	1				
23	1WD–F122A–00	STAY 1	1	1				
24	1WD–F122B–00	STAY 2	1	1				
25	91317–10020	BOLT,HEX.SOCKET HEAD	4	4				
26	91317–10045	BOLT,HEX.SOCKET HEAD	2	2				
27	92907–10600	WASHER, PLATE	6	6				



FIG. 17 FRAME

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	90387–08813	COLLAR	1	1				
29	5TP–E4747–00	DAMPER, MUFFLER	1	1				
30	BS7–F612N–00	BRACKET 5	1	1				
31	90269–05008	RIVET	1	1				
32	90269–07007	RIVET	1	1				
33	2DS–F414E–00	SEAL 2	1	1				

FIG. 18 FENDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–XF151–20–P0	FENDER, FRONT	1	1				UR FOR DPBMC
	BS7–XF151–10–P1	FENDER, FRONT	1	1				UR SMX FOR MBL2
2	1WD–F153E–00	.EMBLEM, YAMAHA	1	1				FOR DPBMC
3	B5P–F1569–00	.GRAPHIC 1	2	2				UR FOR DPBMC
	B5P–F1569–10	.GRAPHIC 1	2	2				UR FOR MBL2
4	90387–06899	.COLLAR	4	4				
5	90387–06899	.COLLAR	2	2				
6	90480–12808	.GROMMET	4	4				
7	90480–12808	.GROMMET	2	2				
8	90111–06137	BOLT,HEX. SOCKET BUTTON	4	4				
9	90111–06847	BOLT,HEX. SOCKET BUTTON	2	2				
10	95702–06500	NUT, FLANGE	2	2				
11	B5L–F113J–00	BRACKET, REFLECTOR 1	1	1				
12	B5L–F113K–01	BRACKET, REFLECTOR 2	1	1				
13	2FC–H5111–00	REFLECTOR, FRONT 1	2	2				
14	95702–05500	NUT, FLANGE	2	2				
15	90464–16006	CLAMP	1	1				
16	BR5–F1611–01	FENDER, REAR	1	1				
17	1WD–F1669–00	SEAL	1	1				
18	90109–063F1	BOLT	4	4				
19	90183–05076	NUT, SPRING	2	2				
20	1WD–F16A2–00	SEAL, 2	1	1				
21	BR5–F163E–00	COVER, REAR FENDER 2	1	1				
22	90269–06816	RIVET	2	2				
23	1WD–F1629–01	GUARD, MUD	1	1				
24	1WD–F1617–00	BRACKET, FENDER	1	1				
25	90111–05021	BOLT,HEX. SOCKET BUTTON	2	2				

FIG. 18 FENDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
26	90183–050A7	NUT, SPRING	4	4				
27	97707–50016	SCREW, TRUSS HEAD TAPPING	4	4				
28	90111–05018	BOLT,HEX. SOCKET BUTTON	4	4				
29	1WD–F1688–00	BRACKET, REAR STAY	1	1				
30	1WD–F1689–00	BRACKET, REAR STAY 2	1	1				
31	90387–066J9	COLLAR	4	4				
32	90387–068L9	COLLAR	2	2				
33	95602–06200	NUT, SELF-LOCKING	4	4				
34	1WD–F1621–00	FLAP	1	1				
35	90109–05003	BOLT	2	2				
36	1WD–F163A–00	COVER, REAR FENDER 1	1	1				
37	90269–06816	RIVET	4	4				

FIG. 19 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–XF171–A0–P1	COVER, SIDE 1	1	1				UR FOR DPBMC
	1WD–XF171–10–P6	COVER, SIDE 1	1	1				UR FOR MBL2
2	90183–05807	.NUT, SPRING	5	5				
3	90183–050A7	.NUT, SPRING	1	1				
4	90480–12808	.GROMMET	1	1				
5	90387–06899	.COLLAR	1	1				
6	31B–F8307–00	.SEAL	1	1				
7	90269–06816	RIVET	1	1				
8	90119–06810	BOLT, WITH WASHER	1	1				
9	1WD–XF172–A0–P1	COVER, SIDE 2	1	1				UR FOR DPBMC
	1WD–XF172–10–P6	COVER, SIDE 2	1	1				UR FOR MBL2
10	90183–05807	.NUT, SPRING	4	4				
11	90183–050A7	.NUT, SPRING	1	1				
12	90480–12808	.GROMMET	1	1				
13	90387–06899	.COLLAR	1	1				
14	31B–F8307–00	.SEAL	1	1				
15	90269–06816	RIVET	1	1				
16	90119–06810	BOLT, WITH WASHER	1	1				
17	1WD–F171L–00	MOLE, SIDE COVER 1	1	1				
18	97707–50016	SCREW, TRUSS HEAD TAPPING	2	2				
19	90269–06816	RIVET	4	4				
20	1WD–F171M–00	MOLE, SIDE COVER 2	1	1				
21	97707–50016	SCREW, TRUSS HEAD TAPPING	3	3				
22	90269–06816	RIVET	4	4				
23	1WD–F171N–00	MOLE, SIDE COVER 3	1	1				
24	97707–50016	SCREW, TRUSS HEAD TAPPING	2	2				
25	1WD–F1871–01	TANK, RECOVERY	1	1				

FIG. 19 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
26	90387–06857	COLLAR	1	1				
27	1WD–F1875–00	CAP	1	1				
28	3C1–F1828–00	ELBOW	1	1				
29	1WD–F1816–00	PIPE 1	1	1				
30	1WD–F1817–00	PIPE 2	1	1				
31	90467–08003	CLIP	3	3				
32	BS7–F172W–00	COVER	1	1				
33	90111–05003	BOLT,HEX. SOCKET BUTTON	2	2				
34	90560–06244	SPACER	2	2				
35	1WD–F1731–00–P4	COVER, SIDE 3	1	1				MBL2
36	90160–05810	SCREW, ROUND TAPPING	2	2				
37	BS7–F171E–00	COVER, SIDE 5	1	1				
38	90338–06018	PLUG	1	1				
39	90111–05003	BOLT,HEX. SOCKET BUTTON	2	2				
40	90520–30805	DAMPER, PLATE	1	1				
41	90520–10850	DAMPER, PLATE	1	1				
42	BS7–F171X–00	COVER, SIDE 6	1	1				
43	90338–06018	PLUG	2	2				
44	90111–05003	BOLT,HEX. SOCKET BUTTON	2	2				
45	90520–30805	DAMPER, PLATE	1	1				
46	90520–10850	DAMPER, PLATE	1	1				
47	1PA–F836B–00	TUNING FORK MARK	1	1				

FIG. 20 REAR ARM & SUSPENSION



B5L1422-U200

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F2110–00	REAR ARM COMP.	1	1				
2	1WD–22141–00	SHAFT, PIVOT	1	1				
3	1WD–F2129–00	COVER, THRUST 2	2	2				
4	1WD–F2184–00	BUSH	1	1				
5	93320–32403	BEARING	2	2				
6	95602–14200	NUT, SELF-LOCKING	1	1				
7	1WD–F2151–00	SEAL, GUARD	1	1				
8	90105–12309	BOLT, FLANGE	1	1				
9	1WD–F248B–00	COLLAR, ROD 1	1	1				
10	95602–12100	NUT, U	1	1				
11	1WD–F2311–01	CASE, CHAIN	1	1				
12	90387–06242	COLLAR	2	2				
13	90111–06119	BOLT,HEX. SOCKET BUTTON	2	2				
14	BS7–F2210–00	SHOCK ABSORBER ASSY, REAR	1	1				
15	90105–12093	BOLT, FLANGE	1	1				
16	95602–12100	NUT, U	1	1				
17	2MS–F1668–00	LABEL, TIRE	1	1				



BS71460-U210

FIG. 21 STEERING

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	93399–999Y3	BEARING	1	1				
2	5BP–F3416–10	COVER, BALL RACE 2	1	1				
3	90179–25615	NUT	2	2				
4	90202–26142	WASHER, PLATE	1	1				
5	5BP–F3418–00	WASHER, SPECIAL	1	1				
6	BS7–F3435–00	CROWN, HANDLE	1	1				
7	90105–14102	BOLT, FLANGE	1	1				
8	91317–08030	BOLT,HEX.SOCKET HEAD	2	2				

FIG. 22 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	B5L–F3100–00	FRONT FORK ASSY	1	1				
2	BS7–F3102–00	.FRONT FORK ASSY (L.H)	1	1				
3	BS7–F3110–00	..INNER TUBE COMP.1	1	1				
4	B48–F3144–00	..SEAL, DUST	1	1				
5	3R4–23153–00	..RING, SNAP	1	1				
6	BK6–F3145–00	..OIL SEAL	1	1				
7	31A–23149–31	..WASHER, SPRING UPPER	1	1				
8	31A–23125–31	..METAL, SLIDE 1	1	1				
9	BK6–F3171–00	..PISTON, FRONT FORK	1	1				
10	BS7–F3126–10	..TUBE, OUTER	1	1				
11	BS7–F3170–00	..CYLINDER COMP., FRONT FORK	1	1				
12	2BU–F3158–00	..GASKET	1	1				
13	31B–F3181–00	..BOLT, HEXAGON SOCKET HEAD	1	1				
14	BS7–F3141–00	..SPRING, FRONT FORK	1	1				
15	BK6–F3117–00	..GUIDE, SPRING	1	1				
16	BS7–F3118–00	..SPACER	1	1				
17	BK6–F3357–00	..NUT	1	1				
18	BS7–F3111–00	..BOLT, CAP	1	1				
19	4V4–23188–L0	..O-RING	1	1				
20	B5L–F3103–00	.FRONT FORK ASSY (R.H)	1	1				
21	B5L–F3120–00	..INNER TUBE COMP.2	1	1				
22	BK6–F330G–00	...ROD COMP.	1	1				
23	3AH–22222–00	...SPRING 2	1	1				
24	BS7–F3141–00	...SPRING, FRONT FORK	1	1				
25	BK6–F319U–00	...CAP	1	1				
26	B48–F3144–00	..SEAL, DUST	1	1				
27	3R4–23153–00	..RING, SNAP	1	1				

FIG. 22 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	BK6–F3145–00	..OIL SEAL	1	1				
29	31A–23149–31	..WASHER, SPRING UPPER	1	1				
30	31A–23125–31	..METAL, SLIDE 1	1	1				
31	BK6–F3171–00	..PISTON, FRONT FORK	1	1				
32	BS7–F3126–10	..TUBE, OUTER	1	1				
33	BK6–F332K–00	..BUMP, STOP	1	1				
34	BK6–F3393–00	..NUT, SPECIAL	1	1				
35	BS7–F3111–00	..BOLT, CAP	1	1				
36	4V4–23188–L0	..O-RING	1	1				
37	BS7–F3340–00	.UNDER BRACKET COMP.	1	1				
38	3FV–23462–00	..SEAL, STEERING	1	1				
39	93399–99932	..BEARING	1	1				
40	91312–10040	.BOLT, HEXAGON SOCKET HEAD	2	2				



FIG. 23 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–F4110–00	FUEL TANK COMP.	1	1				
2	BS7–F4188–00	MOLD, FUEL TANK	2	2				
3	5D9–H2126–00	PAD, BATTERY	1	1				
4	90520–02843	DAMPER, PLATE	1	1				
5	BS7–F414E–00	SEAL 2	1	1				
6	BS7–F412Y–00	BRACKET, TANK FITTING	1	1				
7	90480–18813	GROMMET	2	2				
8	90387–068M3	COLLAR	2	2				
9	97022–06030	BOLT, HEXAGON	2	2				
10	95817–06012	BOLT, FLANGE	2	2				
11	BS7–F4191–10	BRACKET, FUEL TANK 1	1	1				
12	90480–15807	GROMMET	2	2				
13	90387–068S8	COLLAR	2	2				
14	97022–06030	BOLT, HEXAGON	2	2				
15	95022–08014	BOLT, FLANGE	2	2				
16	BS7–WF461–00	CAP ASSY WITH LOCK	1	1				
17	90110–05806	BOLT, HEXAGON SOCKET HEAD	3	3				
18	91312–05010	BOLT, HEXAGON SOCKET HEAD	1	1				
19	90480–01806	GROMMET	1	1				
20	BS7–XF41D–60–P0	TANK SIDE COVER 1	1	1				UR FOR DPBMC
	BS7–XF41D–40–P1	TANK SIDE COVER 1	1	1				UR FOR MBL2
21	90480–12808	.GROMMET	2	2				
22	90387–06899	.COLLAR	2	2				
23	90480–01559	.GROMMET	4	4				
24	26P–21568–10	.LABEL, WARNING	1	1				
25	BB8–F817K–00	.LABEL, FUEL	1	1				
26	90520–03841	DAMPER, PLATE	1	1				



FIG. 23 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
27	90119–06M17	BOLT, WITH WASHER	2	2				
28	90109–068B2	BOLT	2	2				
29	90269–06816	RIVET	2	2				
30	BS7–XF17D–20–P0	COVER, TOP	1	1				UR FOR DPBMC
	BS7–XF17D–00–P1	COVER, TOP	1	1				UR FOR MBL2
31	1WD–F413B–00	.EMBLEM	2	2				
32	B8P–F4244–00	.GRAPHIC	1	1				FOR DPBMC
33	31B–F8307–00	.SEAL	8	8				
34	BS7–E3907–00	FUEL PUMP COMP.	1	1				
35	BS7–H5752–00	.SENDER UNIT ASSY, FUEL METER	1	1				
36	BS7–F4491–00	BRACKET, FUEL PUMP	1	1				
37	3C1–F4486–00	O-RING	1	1				
38	91312–05010	BOLT, HEXAGON SOCKET HEAD	6	6				
39	1WD–E3971–01	PIPE, FUEL 1	1	1				
40	1WD–F4312–00	PIPE 2	1	1				
41	1WD–F4314–00	PIPE 4	1	1				
42	90467–15012	CLIP	3	3				
43	1WD–F4376–00	PIPE, JOINT 1	1	1				
44	90464–16012	CLAMP	1	1				
45	2MS–F4314–01	PIPE 4	1	1				
46	90467–09006	CLIP	2	2				
47	1DW–F4180–02	ROLL OVER VALVE ASSY	1	1				
48	90464–10008	CLAMP	1	1				
49	90269–05008	RIVET	1	1				
50	2MS–F419F–00	BRACKET, CANISTOR	1	1				
51	90464–15014	CLAMP	1	1				
52	95027–08012	BOLT, FLANGE	1	1				



FIG. 23 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
53	2MS–F4315–00	PIPE 5	1	1				
54	90467–09006	CLIP	2	2				
55	2MS–F4170–00	CANISTER ASSY	1	1				
56	2MS–F483H–00	BAND	1	1				
57	2MS–F115R–00	BRACKET, CANISTER	1	1				
58	2MS–F134X–00	BRACKET, CANISTER	1	1				
59	95027–06016	BOLT, FLANGE	2	2				
60	90269–06816	RIVET	1	1				
61	2MS–F4316–00	PIPE 6	1	1				
62	90467–11009	CLIP	1	1				
63	90467–09006	CLIP	1	1				

FIG. 24 SEAT



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F4710–01	SINGLE SEAT ASSY	1	1				
2	1WD–F4711–00	.COVER, SINGLE SEAT	1	1				
3	5BP–F4741–00	.PAD, SEAT	4	4				
4	95022–06012	BOLT, FLANGE	2	2				
5	1WD–F4750–00	TANDEM SEAT ASSY	1	1				
6	3C1–F4741–00	.PAD, SEAT	4	4				
7	1WD–F4780–00	SEAT LOCK ASSY	1	1				
8	1WD–F4792–00	PLATE	1	1				
9	95707–06500	NUT, FLANGE	2	2				
10	1WD–F478E–00	CABLE, SEAT LOCK	1	1				
11	1WD–WF479–00	ROTOR SUB ASSY WITH KEY	1	1				
12	1WD–F117K–00	STAY, LOCK	1	1				
13	90159–06054	SCREW, WITH WASHER	1	1				
14	97702–50016	SCREW, TAPPING	2	2				
15	1WD–F8100–00	TOOL KIT	1	1				
16	5TL–H2131–00	BAND, BATTERY	1	1				
17	B7P–F8199–E0	MANUAL,OWNER'S	1	1				UR ENGLISH
	B7P–F8199–F0	MANUAL,OWNER'S	1					UR FRENCH
	B7P–F8199–G0	MANUAL,OWNER'S	1					UR GERMAN
	B7P–F8199–H0	MANUAL,OWNER'S	1					UR ITALIAN
	B7P–F8199–S0	MANUAL,OWNER'S	1					UR SPANISH
	B7P–F819D–D0	MANUAL,OWNER'S	1					UR DUTCH
	B7P–F819D–M0	MANUAL,OWNER'S	1					UR SWEDISH
	B7P–F819D–P0	MANUAL,OWNER'S	1					UR PORTUGUESE

FIG. 25 FRONT WHEEL



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2WD–F5168–02–P0	CAST WHEEL, FRONT	1	1				DPBM15 FOR DPBMC
	2WD–F5168–02–98	CAST WHEEL, FRONT	1	1				LGB FOR MBL2
2	1WD–F510C–01	COLLAR ASSY.	1	1				
3	93106–26815	OIL SEAL	2	2				
4	93306–302X4	BEARING	2	2				
5	94111–17812	TIRE (110/70R17 M/C 54H)	1	1				DUNLOP
6	93900–00828	VALVE, RIM	1	1				
7	5MT–25398–00	BALANCER, WHEEL (10G)	1	1				UN
	5MT–25398–10	BALANCER, WHEEL (20G)	1	1				UN
	5MT–25398–20	BALANCER, WHEEL (30G)	1	1				UN
8	2DP–F517G–00	ROTOR, SENSOR	1	1				
9	90149–05029	SCREW	3	3				
10	B5L–F514A–00	RING, WHEEL 1	1	1				
11	1PA–F5386–00	COLLAR, SPROCKET AXLE	2	2				
12	1WD–25181–00	AXLE, WHEEL	1	1				
13	95602–14200	NUT, SELF-LOCKING	1	1				



FIG. 26 FRONT BRAKE CALIPER

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F581U–01	DISK BRAKE ASSY (RIGHT)	1	1				
2	90111–08087	BOLT,HEX. SOCKET BUTTON	5	5				
3	1WD–F580U–01	CALIPER ASSY (RIGHT)	1	1				
4	1WD–25802–00	.PISTON ASSY, CALIPER	1	1				
5	1WD–25803–00	..CALIPER SEAL KIT	1	1				
6	4C9–W0048–00	.BLEED SCREW KIT	1	1				
7	5YP–F5937–00	.BOOT 2	1	1				
8	5YP–F5917–00	.BOOT, CALIPER	1	1				
9	5YP–F5925–01	.CLIP	2	2				
10	1WD–F5919–00	.SUPPORT, PAD	1	1				
11	5YP–F5924–00	.PIN, PAD	1	1				
12	1WD–25805–00	.BRAKE PAD KIT	1	1				
13	90149–10044	SCREW	2	2				

FIG. 27 REAR WHEEL



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2WD–F5338–02–P0	CAST WHEEL, REAR	1	1				DPBM15 FOR DPBMC
	2WD–F5338–02–98	CAST WHEEL, REAR	1	1				LGB FOR MBL2
2	90387–17810	COLLAR	1	1				
3	93306–20314	BEARING	2	2				
4	93106–23002	OIL SEAL	1	1				
5	1WD–F5364–00	DAMPER	6	6				
6	1WD–F5366–00–P0	CLUTCH, HUB	1	1				UR FOR DPBMC
	1WD–F5366–00–98	CLUTCH, HUB	1	1				UR LGB FOR MBL2
7	93306–30450	BEARING	1	1				
8	93106–38046	OIL SEAL	1	1				
9	1WD–F5377–00	COLLAR, WHEEL	1	1				
10	1WD–F5443–00	SPROCKET, DRIVEN (43T)	1	1				
11	1WD–F537W–00	BRACKET 1	1	1				
12	1WD–F537X–00	BRKT 2	1	1				
13	1WD–F539F–00	PLATE 1	3	3				
14	90116–10065	BOLT, STUD	6	6				
15	95602–10200	NUT, S/L FLANGE	6	6				
16	94114–17814	TIRE (140/70R17 M/C 66H)	1	1				DUNLOP
17	93900–00828	VALVE, RIM	1	1				
18	5MT–25398–00	BALANCER, WHEEL (10G)	1	1				UN
	5MT–25398–10	BALANCER, WHEEL (20G)	1	1				UN
	5MT–25398–20	BALANCER, WHEEL (30G)	1	1				UN
19	2DP–F517G–00	ROTOR, SENSOR	1	1				
20	90149–05029	SCREW	3	3				
21	1WD–25381–00	AXLE, WHEEL	1	1				
22	1WD–F5386–00	COLLAR, SPROCKET AXLE	1	1				
23	1WD–F5383–00	COLLAR, WHEEL	1	1				

FIG. 27 REAR WHEEL



2WD2460-P271

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
24	95602–16200	NUT, SELF-LOCKING	1	1				
25	90201–17809	WASHER, PLATE	2	2				
26	1WD–F5388–00	PULLER, CHAIN 1	2	2				
27	1WD–F2174–00	END 1	2	2				
28	92902–08600	WASHER, PLATE	2	2				
29	95302–08600	NUT, HEXAGON	4	4				
30	40D–E443G–00	PIPE, DRAIN 2	2	2				
31	94568–H3112	CHAIN (DID520VF 112LE)	1	1				

FIG. 28 REAR BRAKE CALIPER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F582W–00	DISK, REAR BRAKE 2	1	1				
2	90111–08087	BOLT,HEX. SOCKET BUTTON	3	3				
3	2WD–F580W–00	CALIPER ASSY, REAR 2	1	1				
4	1WD–25802–50	.PISTON ASSY, CALIPER	1	1				
5	1WD–25803–50	..CALIPER SEAL KIT	1	1				
6	5YP–F5917–00	.BOOT, CALIPER	1	1				
7	34X–25937–00	.BOOT 2	1	1				
8	5YP–W0048–50	.BLEED SCREW KIT	1	1				
9	1WD–F5919–50	.SUPPORT, PAD	1	1				
10	1WD–F5924–50	.PIN, PAD	1	1				
11	5YP–F5925–01	.CLIP	2	2				
12	2WD–F5921–50	.BRACKET, SUPPORT	1	1				
13	1WD–F5939–51	.CLIP, PAD	1	1				
14	1WD–F5939–61	.CLIP, PAD	1	1				
15	1WD–25806–00	.BRAKE PAD KIT 2	1	1				
16	1WD–F5914–50	.PIN, SLIDE	1	1				
17	5KN–25926–01	.BOLT	1	1				
18	5TL–F5838–00	.SLEEVE, CALIPER	1	1				

FIG. 29 STEERING HANDLE & CABLE



BS72460-U290

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–F6121–00	HANDLEBAR (LEFT)	1	1				
2	91317–08020	BOLT,HEX.SOCKET HEAD	1	1				
3	91317–06016	BOLT,HEX.SOCKET HEAD	1	1				
4	90338–05010	PLUG	1	1				
5	BS7–F6122–00	HANDLEBAR (RIGHT)	1	1				
6	91317–08020	BOLT,HEX.SOCKET HEAD	1	1				
7	91317–06016	BOLT,HEX.SOCKET HEAD	1	1				
8	90338–05010	PLUG	1	1				
9	2DP–F6241–00	GRIP	1	1				
10	2DP–F6240–00	GRIP ASSY	1	1				
11	2MS–F622H–00	WEIGHT	2	2				
12	1S7–F622F–00	DAMPER, LOCATING 1	4	4				
13	1S7–F6257–00	STOPPER	2	2				
14	1WD–F6246–00	END, GRIP	2	2				
15	91317–06020	BOLT,HEX.SOCKET HEAD	2	2				
16	1WD–F6335–00	CABLE, CLUTCH	1	1				
17	BS7–F6131–00	GUIDE, CABLE 1	1	1				
18	B6P–F6301–01	THROTTLE CABLE ASSY	1	1				
19	91312–05010	BOLT, HEXAGON SOCKET HEAD	2	2				

FIG. 30 FRONT MASTER CYLINDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F5870–00	MASTER CYLINDER SUB ASSY	1	1				
2	1WD–F5807–00	.CYLINDER KIT, MASTER	1	1				
3	5RB–25854–00	.DIAPHRAGM, RESERVOIR	1	1				
4	1WD–F5852–00	.CAP, RESERVOIR	1	1				
5	36Y–2589H–00	.SCREW	2	2				
6	3RW–F5867–00	.BRACKET, MASTER CYLINDER	1	1				
7	3C1–F5855–00	.BUSH,DIAPHRAGM	1	1				
8	1WD–H3922–00	LEVER 2	1	1				
9	95602–06100	NUT, SELF-LOCKING	1	1				
10	90109–06577	BOLT	1	1				
11	2DP–H3980–00	FRONT STOP SWITCH ASSY	1	1				
12	97602–04212	SCREW, PAN HEAD WITH WASHER	1	1				
13	95027–06025	BOLT, FLANGE	2	2				
14	90338–09012	PLUG	1	1				
15	95812–06012	BOLT, FLANGE	1	1				
16	2WD–F588F–00	HOLDER, BRAKE HOSE 5	1	1				
17	95022–06020	BOLT, FLANGE	1	1				
18	B5L–F5872–00	HOSE, BRAKE 1	1	1				
19	90401–10812	BOLT, UNION	1	1				
20	90201–10118	WASHER, PLATE	2	2				
21	95022–06020	BOLT, FLANGE	1	1				
22	B5L–F581J–00	HOSE, BRAKE 4	1	1				
23	B5L–F612E–00	BRACKET	1	1				
24	BS7–F3818–00	COVER, STEERING	1	1				
25	90269–06816	RIVET	2	2				
26	B5L–F5887–00	HOLDER, BRAKE HOSE	1	1				
27	90176–06065	NUT, CROWN	1	1				

FIG. 30 FRONT MASTER CYLINDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	B5L–F587A–00	HOLDER, BRAKE HOSE	1	1				
29	90401–10812	BOLT, UNION	1	1				
30	90201–10118	WASHER, PLATE	2	2				
31	2WD–F5873–00	HOSE, BRAKE 2	1	1				
32	90401–10812	BOLT, UNION	2	2				
33	90201–10118	WASHER, PLATE	4	4				
34	B5L–F5874–00	HOSE, BRAKE	1	1				
35	90401–10812	BOLT, UNION	2	2				
36	90201–10118	WASHER, PLATE	4	4				
37	2WD–F588G–00	HOLDER, BRAKE HOSE 6	1	1				
38	95027–06012	BOLT, FLANGE	2	2				
39	95027–06012	BOLT, FLANGE	2	2				

FIG. 31 STAND & FOOTREST



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F7311–00	STAND, SIDE	1	1				
2	1WD–F7321–10	BRACKET, SIDE STAND	1	1				
3	95817–10025	BOLT, FLANGE	2	2				
4	90506–23812	SPRING, TENSION	1	1				
5	90105–106A7	BOLT, FLANGE	1	1				
6	90387–10010	COLLAR	1	1				
7	95602–10200	NUT, S/L FLANGE	1	1				
8	90445–217G3	HOSE (L70)	1	1				
9	1WD–F7442–01	BRACKET 2	1	1				
10	1WD–F7451–00	FOOTREST	1	1				
11	1WD–F7435–00	BOLT	1	1				
12	90508–183B9	SPRING, TORSION	1	1				
13	90240–08145	PIN, CLEVIS	1	1				
14	91401–25015	PIN, COTTER	1	1				
15	2MS–F7445–00	PLATE 1	1	1				
16	90111–06013	BOLT,HEX. SOCKET BUTTON	2	2				
17	90109–085G6	BOLT	2	2				
18	1WD–F7443–00	BRACKET 3	1	1				
19	1WD–F7461–00	FOOTREST	1	1				
20	1WD–F7435–00	BOLT	1	1				
21	90508–183B9	SPRING, TORSION	1	1				
22	90240–08145	PIN, CLEVIS	1	1				
23	91401–25015	PIN, COTTER	1	1				
24	1WD–F7211–00	PEDAL, BRAKE	1	1				
25	4BP–27261–00	SHAFT	1	1				
26	90201–10021	WASHER, PLATE	1	1				
27	90506–26807	SPRING, TENSION	1	1				



FIG. 31 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	1WD–F144G–00	STAY, STOP SWITCH	1	1				
29	95802–06010	BOLT, FLANGE	2	2				
30	90109–085G6	BOLT	2	2				
31	2MS–F7446–00	PLATE 2	1	1				
32	1WD–F7430–01	REAR FOOTREST ASSY 1	1	1				
33	1WD–F7431–01	.FOOTREST, REAR 1	1	1				
34	90501–12743	.SPRING, COMPRESSION	1	1				
35	93501–04830	.BALL	1	1				
36	1WD–F7437–00	.WASHER, SPECIAL	1	1				
37	90240–08145	.PIN, CLEVIS	1	1				
38	91401–25015	.PIN, COTTER	1	1				
39	90110–08071	BOLT, HEXAGON SOCKET HEAD	2	2				
40	1WD–F7440–01	REAR FOOTREST ASSY 2	1	1				
41	1WD–F7441–01	.FOOTREST, REAR 2	1	1				
42	90501–12743	.SPRING, COMPRESSION	1	1				
43	93501–04830	.BALL	1	1				
44	1WD–F7437–00	.WASHER, SPECIAL	1	1				
45	90240–08145	.PIN, CLEVIS	1	1				
46	91401–25015	.PIN, COTTER	1	1				
47	90110–08071	BOLT, HEXAGON SOCKET HEAD	2	2				
48	5TP–E4747–00	DAMPER, MUFFLER	1	1				
49	90387–08813	COLLAR	1	1				

FIG. 32 REAR MASTER CYLINDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–F580E–00	REAR MASTER CYLINDER ASSY	1	1				
2	1WD–F5808–00	.CYLINDER KIT, MASTER	1	1				
3	4SS–27218–00	.NUT	2	2				
4	50C–F7222–00	.JOINT	1	1				
5	50C–F582A–50	.JOINT	1	1				
6	50C–F5866–00	.CIRCLIP	1	1				
7	93210–15620	.O-RING	1	1				
8	3KW–27234–00	.PIN, BRAKE ROD	1	1				
9	50C–F5894–10	.TANK, RESERVOIR	1	1				
10	2VN–F5854–00	.DIAPHRAGM, RESERVOIR	1	1				
11	50C–F5855–00	.BUSH,DIAPHRAGM	1	1				
12	1WD–F5852–50	.CAP, RESERVOIR	1	1				
13	1WD–F5895–50	.HOSE, RESERVOIR	1	1				
14	90467–12085	.CLIP	2	2				
15	50C–F589A–00	.COVER, DUST	1	1				
16	90240–08124	PIN, CLEVIS	1	1				
17	90201–08083	WASHER, PLATE	1	1				
18	91401–20012	PIN, COTTER	1	1				
19	92012–08030	BOLT, BUTTON HEAD	2	2				
20	90111–06121	BOLT,HEX. SOCKET BUTTON	1	1				
21	B04–F582E–00	HOLDER, RESERVE TANK	1	1				
22	2WD–F581K–00	HOSE, BRAKE 5	1	1				
23	90401–10812	BOLT, UNION	2	2				
24	90201–10118	WASHER, PLATE	4	4				
25	2WD–F582J–00	HOSE, BRAKE 6	1	1				
26	90401–10812	BOLT, UNION	2	2				
27	90201–10118	WASHER, PLATE	4	4				

FIG. 32 REAR MASTER CYLINDER



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	2WD–F5887–00	HOLDER, BRAKE HOSE	1	1				
29	95D37–06014	BOLT, FLANGE DEEP RECESS	1	1				
30	90464–30009	CLAMP	1	1				



FIG. 33 WINDSHIELD

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–F8381–00	WINDSHIELD	1	1				
2	90179–05849	NUT	4	4				
3	BS7–F835G–00	BODY, FRONT UPPER 1	1	1				
4	97702–50016	SCREW, TAPPING	4	4				
5	90480–13398	GROMMET	1	1				
6	90520–07808	DAMPER, PLATE	2	2				
7	BS7–XF83F–20–P0	BODY COWLING SUB ASSY	1	1				UR FOR DPBMC
	BS7–XF83F–00–P1	BODY COWLING SUB ASSY	1	1				UR FOR MBL2
8	BS7–F8391–00	.GRAPHIC 1	1	1				UR FOR DPBMC
	BS7–F8391–10	.GRAPHIC 1	1	1				UR FOR MBL2
9	B8P–F8392–00	.GRAPHIC 2	1	1				UR FOR DPBMC
	BS7–F8392–10	.GRAPHIC 2	1	1				UR FOR MBL2
10	90183–05807	.NUT, SPRING	4	4				
11	90520–07808	.DAMPER, PLATE	2	2				
12	31B–F8307–00	.SEAL	6	6				
13	1WD–F8376–00	.TRIM	4	4				
14	BS7–F8393–10	.GRAPHIC 3	1	1				FOR MBL2
15	BS7–F8394–10	.GRAPHIC 4	1	1				FOR MBL2
16	1WD–F414E–00	.SEAL 2	4	4				
17	90150–05023	SCREW, ROUND HEAD	4	4				
18	90202–05088	WASHER, PLATE	4	4				
19	BS7–F836N–00	PANEL, INNER 4	1	1				
20	90269–06816	RIVET	3	3				
21	90111–05003	BOLT,HEX. SOCKET BUTTON	1	1				
22	BS7–F8327–00	DAMPER, LEG SHIELD	1	1				
23	BS7–F836R–00	PANEL, INNER 5	1	1				
24	90269–06816	RIVET	3	3				



FIG. 33 WINDSHIELD

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
25	90111–05003	BOLT,HEX. SOCKET BUTTON	1	1				
26	BS7–F8327–00	DAMPER, LEG SHIELD	1	1				
27	BS7–F8356–00	STAY 1	1	1				
28	95812–08035	BOLT, FLANGE	2	2				
29	BS7–F6280–00	REAR VIEW MIRROR ASSY (LEFT)	1	1				
30	BS7–F6290–00	REAR VIEW MIRROR ASSY (RIGHT)	1	1				
31	BK6–F8483–00	PLATE, RUBBER 1	2	2				
32	BS7–F8484–00	PLATE, RUBBER 2	1	1				
33	BS7–F8485–00	PLATE, RUBBER 3	1	1				
34	91317–06030	BOLT,HEX.SOCKET HEAD	4	4				
35	90387–06131	COLLAR	4	4				
36	90338–05010	PLUG	4	4				

FIG. 34 COWLING 1



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–F172G–00–P0	PANEL 3	1	1				UR FOR DPBMC
	BS7–F172G–00–P1	PANEL 3	1	1				UR SMX FOR MBL2
2	90480–12808	GROMMET	2	2				
3	90387–06899	COLLAR	2	2				
4	90119–06810	BOLT, WITH WASHER	1	1				
5	95702–06500	NUT, FLANGE	1	1				
6	90201–06380	WASHER PLAIN	1	1				
7	97702–50016	SCREW, TAPPING	3	3				
8	90183–050A7	NUT, SPRING	2	2				
9	44D–F8379–00	HOOK	1	1				
10	BS7–F8415–00	DAMPER 1	1	1				
11	BS7–F172H–00–P0	PANEL 4	1	1				UR FOR DPBMC
	BS7–F172H–00–P1	PANEL 4	1	1				UR SMX FOR MBL2
12	90480–12808	GROMMET	2	2				
13	90387–06899	COLLAR	2	2				
14	90119–06810	BOLT, WITH WASHER	2	2				
15	97702–50016	SCREW, TAPPING	3	3				
16	90183–050A7	NUT, SPRING	2	2				
17	BS7–F8415–00	DAMPER 1	1	1				
18	44D–F8379–00	HOOK	1	1				
19	BS7–F117V–00	COVER 7	1	1				
20	97702–50016	SCREW, TAPPING	1	1				
21	BS7–F117W–00	COVER 8	1	1				
22	97702–50016	SCREW, TAPPING	1	1				
23	BS7–F835U–00–P0	PANEL 1	1	1				UR SMX FOR DPBMC
	BS7–F835U–00–P1	PANEL 1	1	1				UR FOR MBL2
24	5YT–24665–00	DAMPER	1	1				



FIG. 34 COWLING 1

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
25	97702–50016	SCREW, TAPPING	1	1				
26	90183–05807	NUT, SPRING	7	7				
27	90480–01821	GROMMET	1	1				
28	BS7–F835V–00–P0	PANEL 2	1	1				UR SMX FOR DPBMC
	BS7–F835V–00–P1	PANEL 2	1	1				UR FOR MBL2
29	5YT–24665–00	DAMPER	1	1				
30	97702–50016	SCREW, TAPPING	1	1				
31	90183–05807	NUT, SPRING	7	7				
32	90480–01821	GROMMET	1	1				
33	BS7–F8385–00–P0	COVER, UNDER	1	1				UR SMX FOR DPBMC
	BS7–F8385–00–P1	COVER, UNDER	1	1				UR FOR MBL2
34	90480–12808	GROMMET	1	1				
35	90387–06899	COLLAR	1	1				
36	90111–06117	BOLT,HEX. SOCKET BUTTON	1	1				
37	90183–05807	NUT, SPRING	4	4				
38	90183–05M02	NUT, SPRING	1	1				
39	BS7–F8395–00–P0	COVER, UNDER 2	1	1				UR SMX FOR DPBMC
	BS7–F8395–00–P1	COVER, UNDER 2	1	1				UR FOR MBL2
40	90480–12808	GROMMET	1	1				
41	90387–06899	COLLAR	1	1				
42	90111–06117	BOLT,HEX. SOCKET BUTTON	1	1				
43	90183–05807	NUT, SPRING	4	4				
44	90183–05M02	NUT, SPRING	1	1				
45	BS7–F833E–00	BRACKET 8	1	1				
46	95022–06012	BOLT, FLANGE	1	1				
47	BS7–F836K–00	PANEL, INNER 1	1	1				
48	97707–50016	SCREW, TRUSS HEAD TAPPING	2	2				



FIG. 34 COWLING 1

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
49	BS7–F836L–00	PANEL, INNER 2	1	1				
50	97707–50016	SCREW, TRUSS HEAD TAPPING	2	2				
51	BS7–F836M–00	PANEL, INNER 3	1	1				
52	97707–50016	SCREW, TRUSS HEAD TAPPING	4	4				
53	BS7–F837V–00	GRILL, AIR OUTLET 1	1	1				
54	97702–50016	SCREW, TAPPING	2	2				
55	90269–06816	RIVET	1	1				
56	BS7–F837W–00	GRILL, AIR OUTLET 2	1	1				
57	97702–50016	SCREW, TAPPING	2	2				
58	90269–06816	RIVET	1	1				
59	BS7–F8393–00	GRAPHIC 3	1	1				FOR DPBMC
60	BS7–F8394–00	GRAPHIC 4	1	1				FOR DPBMC
61	B8P–F8398–00	GRAPHIC 5	1	1				FOR MBL2
62	B8P–F8399–00	GRAPHIC 6	1	1				FOR MBL2
63	1WD–F8328–90	EMBLEM	1	1				UR FOR DPBMC
	1WD–F8328–80	EMBLEM	1	1				UR FOR MBL2
64	1WD–F8328–90	EMBLEM	1	1				UR FOR DPBMC
	1WD–F8328–80	EMBLEM	1	1				UR FOR MBL2

FIG. 35 GENERATOR



B6P2516-U350

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BR5–H1450–00	ROTOR ASSY	1	1				
2	BS7–H1410–00	STATOR ASSY	1	1				
3	91312–06030	BOLT, HEXAGON SOCKET HEAD	3	3				
4	90105–10883	BOLT, FLANGE	1	1				
5	90201–10848	WASHER, PLATE	1	1				
6	90280–05013	KEY, WOODRUFF	1	1				

FIG. 36 STARTING MOTOR



1WD1460-P360

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–H1800–00	STARTING MOTOR ASSY	1	1				
2	1WD–H1801–00	.BRUSH SET	1	1				
3	1WD–H1861–00	.GASKET	2	2				
4	1WD–H1828–00	.BOLT 2	2	2				
5	1WD–H183G–00	.CORD COMP.	1	1				
6	4FP–H182L–00	.O-RING 1	1	1				
7	95022–06025	BOLT, FLANGE	2	2				



BR51300-T370

FIG. 37 FLASHER LIGHT

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–H3310–10	FRONT FLASHER LIGHT ASSY 1	1	1				
2	1KB–83311–00	.BULB, FLASHER (12V-10W)	1	1				
3	3D9–H3333–10	.SCREW, LENS FITTING	1	1				
4	1KB–8333A–00	.LENS COMP 1	1	1				
5	BS7–H3320–10	FRONT FLASHER LIGHT ASSY 2	1	1				
6	1KB–83311–00	.BULB, FLASHER (12V-10W)	1	1				
7	3D9–H3333–10	.SCREW, LENS FITTING	1	1				
8	1KB–8334A–00	.LENS COMP 2	1	1				
9	BD6–H3318–10	STAY, FLASHER 1	2	2				
10	BR5–H3330–00	REAR FLASHER LIGHT ASSY 1	1	1				
11	44C–H3311–10	.BULB (12V-10W)	1	1				
12	3D9–H3358–00	.SCREW, SPECIAL	1	1				
13	3D9–H3333–10	.SCREW, LENS FITTING	1	1				
14	1KB–8334A–00	.LENS COMP 2	1	1				
15	BR5–H3340–00	REAR FLASHER LIGHT ASSY 2	1	1				
16	44C–H3311–10	.BULB (12V-10W)	1	1				
17	3D9–H3358–00	.SCREW, SPECIAL	1	1				
18	3D9–H3333–10	.SCREW, LENS FITTING	1	1				
19	1KB–8333A–00	.LENS COMP 1	1	1				
20	1WD–H3318–00	STAY, FLASHER 1	2	2				



BS71460-U380

FIG. 38 METER

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	B7P–H3500–00	METER ASSY	1					UR EXCEPT FOR GBR
	B7P–H3500–10	METER ASSY		1				UR FOR GBR
2	B5P–H3571–00	.CASE, SPEEDOMETER UPPER	1	1				
3	BS7–H3572–00	.CASE, SPEEDOMETER LOWER	1	1				
4	97707–30020	.SCREW, TAPPING	9	9				
5	BS7–H3519–00	BRACKET, METER	1	1				
6	90480–14229	GROMMET	3	3				
7	97702–50016	SCREW, TAPPING	3	3				
8	90201–05827	WASHER, PLATE	1	1				
9	BS7–H350E–00	BRACKET	1	1				
10	90464–16006	CLAMP	1	1				
11	95022–06010	BOLT, FLANGE	2	2				



FIG. 39 HEADLIGHT

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BS7–H4300–00	HEADLIGHT ASSY	1	1				
2	BS7–H4300–10	HEADLIGHT ASSY	1	1				
3	97702–50016	SCREW, TAPPING	6	6				
4	90520–20825	DAMPER, PLATE	2	2				
5	90480–14229	GROMMET	5	5				
6	90201–05036	WASHER, PLATE	5	5				
7	97702–50016	SCREW, TAPPING	5	5				
8	BS7–F838N–00	DUCT 1	1	1				
9	90183–05807	NUT, SPRING	4	4				
10	97702–50016	SCREW, TAPPING	4	4				
11	90269–05005	RIVET	2	2				

FIG. 40 TAILLIGHT



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–H4710–01	TAILLIGHT UNIT ASSY	1	1				
2	90111–06117	BOLT,HEX. SOCKET BUTTON	2	2				
3	90387–067V1	COLLAR	2	2				
4	90480–13001	GROMMET	2	2				
5	90183–05807	NUT, SPRING	2	2				
6	90480–10003	GROMMET	2	2				
7	1WD–F1732–00	SEAL 1	1	1				
8	BS7–H4740–00	LICENCE LIGHT ASSY	1	1				
9	1WD–H4744–00	.BULB (12V-5W)	1	1				
10	1WD–H4547–00	.CORD, LICENCE LIGHT	1	1				
11	1WD–H4726–00	.SCREW	2	2				
12	1WD–H4753–00	DAMPER	1	1				
13	97707–40020	SCREW, TAPPING	2	2				
14	90201–04804	WASHER, PLATE	2	2				
15	90480–11009	GROMMET	2	2				
16	90387–05042	COLLAR	2	2				



BS71460-U410

FIG. 41 HANDLE SWITCH & LEVER

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	3AY–H3936–00	BAND, SWITCH CORD	1	1				
2	90464–36005	CLAMP	1	1				
3	BS7–H3972–00	SWITCH, HANDLE 4	1	1				
4	98507–04025	.SCREW, PAN HEAD	2	2				
5	BS7–H3975–00	SWITCH, HANDLE 2	1	1				
6	98507–04030	.SCREW, PAN HEAD	2	2				
7	97607–04230	.SCREW, WITH WASHER	1	1				
8	90464–30001	CLAMP	1	1				
9	1WD–H2910–00	LEVER HOLDER ASSY (LEFT)	1	1				
10	1WD–H2911–00	.HOLDER, LEVER 1	1	1				
11	1WD–H3912–00	.LEVER 1	1	1				
12	31A–83945–00	.BOLT, LEVER	1	1				
13	31A–83913–00	.COLLAR, LEVER 1	1	1				
14	93210–108H5	.O-RING	1	1				
15	95602–06100	.NUT, SELF-LOCKING	1	1				
16	5BP–H2917–00	.SWITCH	1	1				
17	90151–03005	.SCREW, COUNTERSUNK	1	1				
18	90123–08083	.BOLT	1	1				
19	90179–08316	.NUT	1	1				
20	97507–06525	.BOLT, WITH WASHER	1	1				
21	90338–09012	PLUG	1	1				
22	90464–13227	CLAMP	1	1				
23	90464–08009	CLAMP	1	1				

FIG. 42 ELECTRICAL 1



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	1WD–H2310–00	IGNITION COIL ASSY	2	2				
2	B04–H2314–00	COVER, IGNITION COIL	1	1				
3	B04–H2314–10	COVER, IGNITION COIL	1	1				
4	95022–06020	BOLT, FLANGE	2	2				
5	BR5–H2370–00	PLUG CAP ASSY	2	2				
6	1WD–H2100–00	BATTERY ASSY (GS GTZ8V)	1	1				
7	1WD–H2121–00	PAD, BATTERY	1	1				
8	1WD–H2131–00	BAND, BATTERY	1	1				
9	B7P–H2590–00	WIRE HARNESS ASSY	1	1				
10	1WD–H2151–20	.FUSE (7.5A BL)	4	4				
11	1WD–H2151–10	.FUSE (15A-BL)	4	4				
12	1WD–H2151–30	.FUSE (30A)	2	2				
13	4B4–H1980–00	.DIODE ASSY	1	1				
14	1WD–H2151–90	.FUSE (2A)	2	2				
15	1WD–H1950–00	RELAY ASSY	3	3				
16	1WD–H1940–00	STARTER RELAY ASSY	1	1				
17	1WD–H2151–01	.FUSE (30A)	2	2				
18	91312–05008	BOLT, HEXAGON SOCKET HEAD	2	2				
19	2WD–H2115–00	WIRE, PLUS LEAD	1	1				
20	BR5–H2116–00	WIRE, MINUS LEAD	1	1				
21	90464–36800	CLAMP	2	2				
22	90464–70800	CLAMP	6	6				
23	90464–22800	CLAMP	1	1				
24	90464–70800	CLAMP	1	1				
25	BS7–H2501–00	MAIN SWITCH STEERING LOCK	1	1				
26	1WD–H2511–09	BLANK KEY	1	1				AP
27	90109–060G4	BOLT	2	2				



FIG. 42 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	BS7–XH250–00	MAIN SW. STRG. LOCK SUB ASSY	1	1				AP
29	1WD–H2566–00	SWITCH, SIDE STAND	1	1				
30	90110–05809	BOLT, HEXAGON SOCKET HEAD	2	2				
31	1WD–H2591–00	BAND	1	1				
32	90464–26001	CLAMP	1	1				
33	90464–08009	CLAMP	1	1				
34	2D1–82589–00	PROTECTER, WIRE HARNESS	1	1				

FIG. 43 ELECTRICAL 2



REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	BR5–H591A–00	ENGINE CONTROL UNIT ASSY	1	1				
2	BR5–H5546–00	BAND	1	1				
3	1WD–H2540–00	NEUTRAL SWITCH ASSY	1	1				
4	93210–21801	O-RING	1	1				
5	98502–05016	SCREW,PAN HEAD	2	2				
6	54P–H3591–00	THERMO UNIT	1	1				
7	90430–10804	GASKET	1	1				
8	1WD–H592A–00	SENSOR, OXYGEN	1	1				
9	2WD–E5189–00	PLUG	1	1				
10	93210–15566	O-RING	1	1				
11	91332–06016	BOLT	1	1				
12	1WS–82504–00	OIL PRESSURE SWITCH ASSY	1	1				
13	1WD–H1315–01	LEAD WIRE ASSY	1	1				
14	BR5–H1961–00	COVER	1	1				
15	95D02–06016	BOLT, FLANGE DEEP RECESS	2	2				
16	1WD–H1960–00	RECTIFIER & REGULATOR ASSY	1	1				
17	95D02–06025	BOLT, FLANGE DEEP RECESS	2	2				
18	BR5–H2592–00	BAND	1	1				
19	1WD–H2530–10	STOP SWITCH ASSY	1	1				
20	1WD–H2576–00	SENSOR, LEAN ANGLE	1	1				
21	90160–04009	SCREW, ROUND TAPPING	2	2				
22	90201–04028	WASHER, PLATE	2	2				
23	4B4–84334–00	NUT, ADJUSTING	2	2				
24	3XV–83350–21	FLASHER RELAY ASSY	1	1				
25	1WD–H3371–00	HORN	1	1				
26	95D02–08012	BOLT, FLANGE DEEP RECESS	1	1				
27	1WD–H3378–00	STAY, HORN	1	1				



FIG. 43 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
28	95D07–06016	BOLT, FLANGE DEEP RECESS	2	2				
29	3C1–H5130–00	REAR REFLECTOR ASSY	1	1				
30	95602–05100	NUT, U	1	1				
31	90201–05043	WASHER, PLATE	1	1				



FIG. 44 ELECTRICAL 3

REF. NO.	PART NO.	DESCRIPTION	B7P1	B7P3				REMARKS
1	2WD–85930–09	HYDRAULIC UNIT ASSY	1	1				
2	2WD–F175T–00	BRACKET 1	1	1				
3	95022–06010	BOLT, FLANGE	3	3				
4	95022–06025	BOLT, FLANGE	3	3				
5	90387–06M60	COLLAR	3	3				
6	90480–14229	GROMMET	3	3				
7	2WD–F5886–00	HOLDER, BRAKE HOSE	1	1				
8	95027–06012	BOLT, FLANGE	1	1				
9	2WD–F5875–00	HOLDER, BRAKE HOSE 1	1	1				
10	95027–06012	BOLT, FLANGE	2	2				
11	2WD–85970–00	WHEEL SENSOR ASSY, FRONT	1	1				
12	90464–22800	CLAMP	1	1				
13	95027–06016	BOLT, FLANGE	1	1				
14	90464–12013	CLAMP	4	4				
15	B5L–F3318–00	WIRE, HOLDER 1	1	1				
16	2WD–F3319–00	WIRE, HOLDER 2	1	1				
17	91317–06012	BOLT,HEX.SOCKET HEAD	1	1				
18	2WD–85980–00	WHEEL SENSOR ASSY, REAR	1	1				
19	92012–06016	BOLT, BUTTON HEAD	1	1				
20	90464–14803	CLAMP	1	1				
21	90464–10800	CLAMP	1	1				
22	90464–14803	CLAMP	1	1				

PART NO.	REF. NO.
2MS–11361–00	1 – 9
1WD–11411–00	2 – 1
1WD–11413–00	2 – 23
1WD–11413–10	2 – 23
1WD–11413–20	2 – 23
1WD–11413–30	2 – 23
1WD–11413–40	2 – 23
1WD–11416–00	2 – 10
1WD–11416–10	2 – 10
1WD–11416–20	2 – 10
1WD–11416–30	2 – 10
1WD–11416–40	2 – 10
1WD–11650–00	2 – 2
5SL–11654–00	2 – 3
1WD–11656–00	2 – 5
1WD–11656–10	2 – 5
1WD–11656–20	2 – 5
1WD–11656–30	2 – 5
1HX–12168–F0	3 – 8
1HX–12168–H1	3 – 8
1HX–12168–K1	3 – 8
1HX–12168–M1	3 – 8
1HX–12168–R1	3 – 8
1HX–12168–U1	3 – 8
1HX–12168–W1	3 – 8
1HX–12168–Y1	3 – 8
1HX–12169–11	3 – 8
1HX–12169–31	3 – 8
1HX–12169–50	3 – 8
1HX–12169–70	3 – 8
1HX–12169–90	3 – 8
1HX–12169–E0	3 – 8
1HX–12169–G0	3 – 8
1HX–12169–J0	3 – 8
1HX–12169–L0	3 – 8
1HX–12169–N0	3 – 8
1HX–12169–T0	3 – 8
2MS–12210–00	4 – 6
5P0–12411–00	6 – 1
5NL–12564–00	1 – 28
8GL–13571–00	8 – 14
5JW–14104–00	8 – 20
8A7–14139–00	8 – 18
5PS–14147–00	8 – 7
895–14169–00	8 – 17
1WS–14335–00	8 – 16
8HG–14534–00	8 – 15
5VY–1482K–00	1 – 20
2H7–15361–00	5 – 18
1WD–16382–00	13 – 19
1WD–17424–00	14 – 28
278–17425–00	14 – 12
	14 – 29
26P–21568–10	23 – 24
1WD–22141–00	20 – 2
3AH–22222–00	22 – 23
31A–23125–31	22 – 8
	22 – 30
31A–23149–31	22 – 7
	22 – 29
3R4–23153–00	22 – 5
	22 – 27
4V4–23188–L0	22 – 19
	22 – 36
3FV–23462–00	22 – 38
5YT–24665–00	34 – 24
	34 – 29
1WD–25181–00	25 – 12
1WD–25381–00	27 – 21
5MT–25398–00	25 – 7
	27 – 18
5MT–25398–10	25 – 7
	27 – 18
5MT–25398–20	25 – 7
	27 – 18
1WD–25802–00	26 – 4
1WD–25802–50	28 – 4
1WD–25803–00	26 – 5
1WD–25803–50	28 – 5
1WD–25805–00	26 – 12
1WD–25806–00	28 – 15
5RB–25854–00	30 – 3
36Y–2589H–00	30 – 5
5KN–25926–01	28 – 17
34X–25937–00	28 – 7
4SS–27218–00	32 – 3
3KW–27234–00	32 – 8
4BP–27261–00	31 – 25
1WS–82504–00	43 – 12
2D1–82589–00	42 – 34
1KB–83311–00	37 – 2
	37 – 6
1KB–8333A–00	37 – 4
	37 – 19
1KB–8334A–00	37 – 8
	37 – 14
3XV–83350–21	43 – 24
31A–83913–00	41 – 13
31A–83945–00	41 – 12
4B4–84334–00	43 – 23
1WS–85801–00	8 – 11
2WD–85930–09	44 – 1
2WD–85970–00	44 – 11
2WD–85980–00	44 – 18
BR5–E1102–10	1 – 1
1WD–E111G–00	1 – 16
	1 – 25
1WD–E1133–10	1 – 3
2MS–E1133–10	1 – 2
BR5–E1181–00	1 – 13
1WD–E1191–00	1 – 17
1WD–E1193–00	1 – 19
4YS–E1198–00	7 – 15
2MS–E1311–10	1 – 26
1WD–E1351–00	1 – 27
1WD–E1411–00	2 – 1
1WD–E1454–00	2 – 22
1WD–E1496–00	2 – 18
1WD–E1531–00	2 – 15
1WD–E1536–00	2 – 6
1WD–E1549–00	2 – 7
BR5–E1603–00	2 – 12
BR5–E1631–00	2 – 11
1WD–E1633–00	2 – 13
2MS–E2111–00	3 – 1
BR5–E2113–00	3 – 4
2MS–E2117–00	3 – 5
3S0–E2118–00	3 – 6
1PA–E2119–00	3 – 7
2MS–E2121–00	3 – 2
2MS–E2126–00	3 – 3
2MS–E2153–11	3 – 9
BR5–E2170–00	4 – 1
1WD–E2176–00	4 – 3
BR5–E2180–00	4 – 2
1WD–E2213–00	4 – 9
33S–E2223–00	5 – 8
1WD–E2241–00	1 – 18
1WD–E2251–00	4 – 11
2MS–E2252–01	4 – 12
1WD–E2256–00	4 – 14
2MS–E2405–00	6 – 9
1WD–E2413–00	6 – 2
1WD–E2420–00	5 – 1
1WD–E2422–00	5 – 14
1WD–E2428–00	5 – 15
1WD–E2450–00	5 – 6
1WD–E2453–00	5 – 7
33S–E2456–00	5 – 9
1WD–E2461–00	6 – 8
5ST–E2462–00	6 – 12
1WD–E2577–00	6 – 4
1WD–E2578–00	6 – 5
1WD–E2671–00	6 – 10
5YP–E2675–00	6 – 11
1WD–E2681–00	5 – 12
1WD–E319L–00	5 – 10
1WD–E3300–01	7 – 1
1WD–E3341–00	7 – 3
1WD–E3342–00	7 – 4
1WD–E3410–00	7 – 9
1WD–E3414–00	7 – 16
1WD–E3415–00	7 – 10
1WD–E3417–00	7 – 13
1WD–E3440–10	7 – 11
54P–E3474–00	8 – 39
BR5–E3543–00	8 – 41
1WD–E3556–00	8 – 8
1WD–E3573–00	8 – 13
2MS–E3586–00	8 – 1
BR5–E3750–01	8 – 5
1WD–E3761–00	8 – 6
BS7–E3907–00	23 – 34
1WD–E3938–00	8 – 12
1WD–E3971–01	23 – 39
54P–E416A–00	8 – 19
1WD–E4243–00	8 – 10
BR5–E4411–00	8 – 25
BR5–E4412–00	8 – 29
1WD–E4422–00	8 – 33
BR5–E4437–00	8 – 28
52B–E443E–00	8 – 37
40D–E443G–00	27 – 30
1WD–E4451–00	8 – 36
1WD–E4452–00	8 – 30
1WD–E4457–00	8 – 31
1WD–E4462–00	8 – 34
2MS–E4465–00	8 – 21
2MS–E4466–00	8 – 22
2MS–E4469–00	8 – 26
2MS–E446C–00	8 – 27
2MS–E4602–00	9 – 1
1WD–E4613–00	9 – 21
1WD–E4628–00	9 – 27
BR5–E4710–00	9 – 6
54D–E4714–00	9 – 15
1WD–E4715–00	9 – 16
1WD–E4728–00	9 – 10
1WD–E473L–00	9 – 2
5TP–E4747–00	9 – 4
	17 – 29
	31 – 48
1WD–E4758–00	9 – 7
1WD–E4763–00	9 – 14
1WD–E4775–00	9 – 5
1WD–E4840–00	1 – 31
1WD–E4881–00	1 – 32
1WD–E4882–01	1 – 34
1WD–E4890–00	1 – 21
1WD–E4899–00	1 – 22
1WD–E5148–00	10 – 4
1WD–E5150–20	10 – 1
1WD–E5155–00	10 – 13
2WD–E5189–00	43 – 9
1WD–E5362–00	5 – 19
2MS–E5373–01	8 – 44
1WD–E5377–00	11 – 21
1WD–E5411–00	11 – 1
1WD–E5413–10	11 – 16
1WD–E5418–00	11 – 22
1WD–E5421–00	5 – 2
2MS–E5441–00	11 – 14
1WD–E5451–00	11 – 7
1WD–E5461–00	11 – 10
1WD–E5462–00	11 – 17
1WD–E5514–00	12 – 1
1WD–E5515–10	12 – 3
44D–E5521–00	12 – 2
1WD–E5580–00	12 – 4
1WD–E6111–00	13 – 1
2MS–E6150–00	13 – 2
1WD–E6154–00	13 – 3
1WD–E6181–00	13 – 13
1WD–E6324–00	13 – 6
1WD–E6331–00	13 – 5
2MS–E6333–10	13 – 8
1WD–E6337–00	13 – 9
2MS–E6340–00	13 – 15
2MS–E6350–01	13 – 7
1WD–E6356–00	13 – 14
2MS–E6371–00	13 – 4
2MS–E7121–00	14 – 7
2MS–E7131–00	14 – 5
2MS–E7151–00	14 – 2
2MS–E7161–00	14 – 6
2MS–E7211–00	14 – 23
2MS–E7221–00	14 – 14
2MS–E7231–00	14 – 18
2MS–E7241–00	14 – 19
2MS–E7251–00	14 – 22
2MS–E7261–00	14 – 17
1WD–E7402–00	14 – 13
2MS–E7411–00	14 – 1
1WD–E7460–00	14 – 31
1WD–E8101–00	16 – 4
1WD–E8110–00	16 – 11
1WD–E8111–00	16 – 12
1WD–E8112–00	16 – 17
1EG–E8113–01	16 – 13
1WD–E8115–00	16 – 14
1WD–E8127–10	16 – 2
1WD–E8140–00	16 – 8
1WD–E8175–00	16 – 3
1WD–E8337–00	16 – 1
1WD–E8511–00	15 – 4
1WD–E8512–00	15 – 5
1WD–E8513–00	15 – 6
1WD–E8531–00	15 – 7
1WD–E8536–00	15 – 9
1WD–E8540–10	15 – 1
5TP–E8542–00	15 – 2
1WD–E8562–00	15 – 10
1WD–F1110–12	17 – 1
1WD–F112C–00	17 – 2
B5L–F113J–00	18 – 11
B5L–F113K–01	18 – 12
2MS–F115R–00	23 – 57
1WD–F1171–00	17 – 16
1WD–F117G–00	17 – 3
1WD–F117K–00	24 – 12
BS7–F117V–00	34 – 19
BS7–F117W–00	34 – 21
1WD–F122A–00	17 – 23
1WD–F122B–00	17 – 24
2MS–F134X–00	23 – 58
1WD–F135F–00	17 – 14
1WD–F144G–00	31 – 28
1WD–F153E–00	18 – 2

PART NO.	REF. NO.
B5P–F1569–00	18 – 3
B5P–F1569–10	18 – 3
BR5–F1611–01	18 – 16
1WD–F1617–00	18 – 24
1WD–F1621–00	18 – 34
1WD–F1629–01	18 – 23
1WD–F163A–00	18 – 36
BR5–F163E–00	18 – 21
1WD–F1652–00	17 – 4
2MS–F1668–00	20 – 17
1WD–F1669–00	18 – 17
1WD–F1688–00	18 – 29
1WD–F1689–00	18 – 30
1WD–F16A2–00	18 – 20
BS7–F171E–00	19 – 37
1WD–F171L–00	19 – 17
1WD–F171M–00	19 – 20
1WD–F171N–00	19 – 23
BS7–F171X–00	19 – 42
BS7–F172G–00–P0	34 – 1
BS7–F172G–00–P1	34 – 1
BS7–F172H–00–P0	34 – 11
BS7–F172H–00–P1	34 – 11
BS7–F172W–00	19 – 32
1WD–F1731–00–P4	19 – 35
1WD–F1732–00	40 – 7
2WD–F175T–00	44 – 2
1WD–F1816–00	19 – 29
1WD–F1817–00	19 – 30
3C1–F1828–00	19 – 28
1WD–F1871–01	19 – 25
1WD–F1875–00	19 – 27
1WD–F191B–00	17 – 8
1WD–F193A–00	17 – 5
1WD–F2110–00	20 – 1
1WD–F2129–00	20 – 3
1WD–F2151–00	20 – 7
1WD–F2174–00	27 – 27
1WD–F2184–00	20 – 4
BS7–F2210–00	20 – 14
1WD–F2311–01	20 – 11
1WD–F248B–00	20 – 9
B5L–F3100–00	22 – 1
BS7–F3102–00	22 – 2
B5L–F3103–00	22 – 20
BS7–F3110–00	22 – 3
BS7–F3111–00	22 – 18
	22 – 35

PART NO.	REF. NO.
BK6–F3117–00	22 – 15
BS7–F3118–00	22 – 16
B5L–F3120–00	22 – 21
BS7–F3126–10	22 – 10
	22 – 32
BS7–F3141–00	22 – 14
	22 – 24
B48–F3144–00	22 – 4
	22 – 26
BK6–F3145–00	22 – 6
	22 – 28
2BU–F3158–00	22 – 12
BS7–F3170–00	22 – 11
BK6–F3171–00	22 – 9
	22 – 31
31B–F3181–00	22 – 13
BK6–F319U–00	22 – 25
BK6–F330G–00	22 – 22
B5L–F3318–00	44 – 15
2WD–F3319–00	44 – 16
BK6–F332K–00	22 – 33
BS7–F3340–00	22 – 37
BK6–F3357–00	22 – 17
BK6–F3393–00	22 – 34
5BP–F3416–10	21 – 2
5BP–F3418–00	21 – 5
BS7–F3435–00	21 – 6
BS7–F3818–00	30 – 24
BS7–F4110–00	23 – 1
BS7–F412Y–00	23 – 6
1WD–F413B–00	23 – 31
1WD–F414E–00	33 – 16
2DS–F414E–00	17 – 33
BS7–F414E–00	23 – 5
5D9–F414G–00	17 – 6
2MS–F4170–00	23 – 55
1DW–F4180–02	23 – 47
BS7–F4188–00	23 – 2
BS7–F4191–10	23 – 11
2MS–F419F–00	23 – 50
B8P–F4244–00	23 – 32
1WD–F4312–00	23 – 40
1WD–F4314–00	23 – 41
2MS–F4314–01	23 – 45
2MS–F4315–00	23 – 53
2MS–F4316–00	23 – 61
1WD–F4376–00	23 – 43
3C1–F4486–00	23 – 37

PART NO.	REF. NO.
BS7–F4491–00	23 – 36
1WD–F4710–01	24 – 1
1WD–F4711–00	24 – 2
3C1–F4741–00	24 – 6
5BP–F4741–00	24 – 3
1WD–F4750–00	24 – 5
1WD–F4780–00	24 – 7
1WD–F478E–00	24 – 10
1WD–F4792–00	24 – 8
2MS–F483H–00	23 – 56
1WD–F510C–01	25 – 2
B5L–F514A–00	25 – 10
2WD–F5168–02–98	25 – 1
2WD–F5168–02–P0	25 – 1
2DP–F517G–00	25 – 8
	27 – 19
2WD–F5338–02–98	27 – 1
2WD–F5338–02–P0	27 – 1
1WD–F5364–00	27 – 5
1WD–F5366–00–98	27 – 6
1WD–F5366–00–P0	27 – 6
1WD–F5377–00	27 – 9
1WD–F537W–00	27 – 11
1WD–F537X–00	27 – 12
1WD–F5383–00	27 – 23
1PA–F5386–00	25 – 11
1WD–F5386–00	27 – 22
1WD–F5388–00	27 – 26
1WD–F539F–00	27 – 13
1WD–F5443–00	27 – 10
1WD–F5807–00	30 – 2
1WD–F5808–00	32 – 2
1WD–F580E–00	32 – 1
1WD–F580U–01	26 – 3
2WD–F580W–00	28 – 3
B5L–F581J–00	30 – 22
2WD–F581K–00	32 – 22
1WD–F581U–01	26 – 1
50C–F582A–50	32 – 5
B04–F582E–00	32 – 21
2WD–F582J–00	32 – 25
1WD–F582W–00	28 – 1
5TL–F5838–00	28 – 18
1WD–F5852–00	30 – 4
1WD–F5852–50	32 – 12
2VN–F5854–00	32 – 10
3C1–F5855–00	30 – 7
50C–F5855–00	32 – 11

PART NO.	REF. NO.
50C–F5866–00	32 – 6
3RW–F5867–00	30 – 6
1WD–F5870–00	30 – 1
B5L–F5872–00	30 – 18
2WD–F5873–00	30 – 31
B5L–F5874–00	30 – 34
2WD–F5875–00	44 – 9
B5L–F587A–00	30 – 28
2WD–F5886–00	44 – 7
2WD–F5887–00	32 – 28
B5L–F5887–00	30 – 26
2WD–F588F–00	30 – 16
2WD–F588G–00	30 – 37
50C–F5894–10	32 – 9
1WD–F5895–50	32 – 13
50C–F589A–00	32 – 15
1WD–F5914–50	28 – 16
5YP–F5917–00	26 – 8
	28 – 6
1WD–F5919–00	26 – 10
1WD–F5919–50	28 – 9
2WD–F5921–50	28 – 12
5YP–F5924–00	26 – 11
1WD–F5924–50	28 – 10
5YP–F5925–01	26 – 9
	28 – 11
5YP–F5937–00	26 – 7
1WD–F5939–51	28 – 13
1WD–F5939–61	28 – 14
BS7–F6121–00	29 – 1
BS7–F6122–00	29 – 5
B5L–F612E–00	30 – 23
BS7–F612N–00	17 – 30
BS7–F6131–00	29 – 17
1S7–F622F–00	29 – 12
2MS–F622H–00	29 – 11
2DP–F6240–00	29 – 10
2DP–F6241–00	29 – 9
1WD–F6246–00	29 – 14
1S7–F6257–00	29 – 13
BS7–F6280–00	33 – 29
BS7–F6290–00	33 – 30
B6P–F6301–01	29 – 18
1WD–F6335–00	29 – 16
1WD–F7211–00	31 – 24
50C–F7222–00	32 – 4
BS8–F7261–00	16 – 18
1WD–F7311–00	31 – 1

PART NO.	REF. NO.
1WD–F7321–10	31 – 2
1WD–F7430–01	31 – 32
1WD–F7431–01	31 – 33
1WD–F7435–00	31 – 11
	31 – 20
1WD–F7437–00	31 – 36
	31 – 44
1WD–F7440–01	31 – 40
1WD–F7441–01	31 – 41
1WD–F7442–01	31 – 9
1WD–F7443–00	31 – 18
2MS–F7445–00	31 – 15
2MS–F7446–00	31 – 31
1WD–F7451–00	31 – 10
1WD–F7461–00	31 – 19
1WD–F8100–00	24 – 15
BB8–F817K–00	23 – 25
B7P–F8199–E0	24 – 17
B7P–F8199–F0	24 – 17
B7P–F8199–G0	24 – 17
B7P–F8199–H0	24 – 17
B7P–F8199–S0	24 – 17
B7P–F819D–D0	24 – 17
B7P–F819D–M0	24 – 17
B7P–F819D–P0	24 – 17
31B–F8307–00	19 – 6
	19 – 14
	23 – 33
	33 – 12
BS7–F8327–00	33 – 22
	33 – 26
1WD–F8328–80	34 – 63
	34 – 64
1WD–F8328–90	34 – 63
	34 – 64
BS7–F833E–00	34 – 45
BS7–F8356–00	33 – 27
BS7–F835G–00	33 – 3
BS7–F835U–00–P0	34 – 23
BS7–F835U–00–P1	34 – 23
BS7–F835V–00–P0	34 – 28
BS7–F835V–00–P1	34 – 28
1PA–F836B–00	19 – 47
BS7–F836K–00	34 – 47
BS7–F836L–00	34 – 49
BS7–F836M–00	34 – 51
BS7–F836N–00	33 – 19
BS7–F836R–00	33 – 23

PART NO.	REF. NO.
1WD–F8376–00	33 – 13
44D–F8379–00	34 – 9
	34 – 18
BS7–F837V–00	34 – 53
BS7–F837W–00	34 – 56
BS7–F8381–00	33 – 1
BS7–F8385–00–P0	34 – 33
BS7–F8385–00–P1	34 – 33
BS7–F838N–00	39 – 8
BS7–F8391–00	33 – 8
BS7–F8391–10	33 – 8
B8P–F8392–00	33 – 9
BS7–F8392–10	33 – 9
BS7–F8393–00	34 – 59
BS7–F8393–10	33 – 14
BS7–F8394–00	34 – 60
BS7–F8394–10	33 – 15
BS7–F8395–00–P0	34 – 39
BS7–F8395–00–P1	34 – 39
B8P–F8398–00	34 – 61
B8P–F8399–00	34 – 62
BS7–F8415–00	34 – 10
	34 – 17
BK6–F8483–00	33 – 31
BS7–F8484–00	33 – 32
BS7–F8485–00	33 – 33
1WD–H1315–01	43 – 13
BS7–H1410–00	35 – 2
BR5–H1450–00	35 – 1
1WD–H1800–00	36 – 1
1WD–H1801–00	36 – 2
1WD–H1828–00	36 – 4
4FP–H182L–00	36 – 6
1WD–H183G–00	36 – 5
1WD–H1861–00	36 – 3
1WD–H1940–00	42 – 16
1WD–H1950–00	42 – 15
1WD–H1960–00	43 – 16
BR5–H1961–00	43 – 14
4B4–H1980–00	42 – 13
1WD–H2100–00	42 – 6
2WD–H2115–00	42 – 19
BR5–H2116–00	42 – 20
1WD–H2121–00	42 – 7
5D9–H2126–00	23 – 3
1WD–H2131–00	42 – 8
5TL–H2131–00	24 – 16
1WD–H2151–01	42 – 17

PART NO.	REF. NO.
1WD–H2151–10	42 – 11
1WD–H2151–20	42 – 10
1WD–H2151–30	42 – 12
1WD–H2151–90	42 – 14
1WD–H2310–00	42 – 1
B04–H2314–00	42 – 2
B04–H2314–10	42 – 3
BR5–H2370–00	42 – 5
BS7–H2501–00	42 – 25
1WD–H2511–09	42 – 26
1WD–H2530–10	43 – 19
1WD–H2540–00	43 – 3
1WD–H2566–00	42 – 29
1WD–H2576–00	43 – 20
B7P–H2590–00	42 – 9
1WD–H2591–00	42 – 31
BR5–H2592–00	43 – 18
1WD–H2910–00	41 – 9
1WD–H2911–00	41 – 10
5BP–H2917–00	41 – 16
BS7–H3310–10	37 – 1
44C–H3311–10	37 – 11
	37 – 16
1WD–H3318–00	37 – 20
BD6–H3318–10	37 – 9
BS7–H3320–10	37 – 5
BR5–H3330–00	37 – 10
3D9–H3333–10	37 – 3
	37 – 7
	37 – 13
	37 – 18
BR5–H3340–00	37 – 15
3D9–H3358–00	37 – 12
	37 – 17
1WD–H3371–00	43 – 25
1WD–H3378–00	43 – 27
B7P–H3500–00	38 – 1
B7P–H3500–10	38 – 1
BS7–H350E–00	38 – 9
BS7–H3519–00	38 – 5
B5P–H3571–00	38 – 2
BS7–H3572–00	38 – 3
54P–H3591–00	43 – 6
1WD–H3912–00	41 – 11
1WD–H3922–00	30 – 8
3AY–H3936–00	41 – 1
BS7–H3972–00	41 – 3
BS7–H3975–00	41 – 5

PART NO.	REF. NO.
2DP–H3980–00	30 – 11
BS7–H4300–00	39 – 1
BS7–H4300–10	39 – 2
1WD–H4547–00	40 – 10
1WD–H4710–01	40 – 1
1WD–H4726–00	40 – 11
BS7–H4740–00	40 – 8
1WD–H4744–00	40 – 9
1WD–H4753–00	40 – 12
2FC–H5111–00	18 – 13
3C1–H5130–00	43 – 29
BR5–H5546–00	43 – 2
BS7–H5752–00	23 – 35
BR5–H591A–00	43 – 1
1WD–H592A–00	43 – 8
4C9–W0048–00	26 – 6
5YP–W0048–50	28 – 8
BS7–WF461–00	23 – 16
1WD–WF479–00	24 – 11
BS7–XF151–10–P1	18 – 1
BS7–XF151–20–P0	18 – 1
1WD–XF171–10–P6	19 – 1
1WD–XF171–A0–P1	19 – 1
1WD–XF172–10–P6	19 – 9
1WD–XF172–A0–P1	19 – 9
BS7–XF17D–00–P1	23 – 30
BS7–XF17D–20–P0	23 – 30
BS7–XF41D–40–P1	23 – 20
BS7–XF41D–60–P0	23 – 20
BS7–XF83F–00–P1	33 – 7
BS7–XF83F–20–P0	33 – 7
BS7–XH250–00	42 – 28
90105–06027	1 – 4
90105–07800	4 – 4
90105–088F7	10 – 6
90105–088F8	2 – 16
90105–088G0	10 – 7
90105–088G7	9 – 23
90105–106A7	31 – 5
90105–10883	2 – 8
	35 – 4
90105–10889	17 – 11
90105–10891	17 – 12
90105–12093	20 – 15
90105–12309	20 – 8
90105–14102	21 – 7
90109–05003	18 – 35
90109–060G4	42 – 27

PART NO.	REF. NO.
90109–063F1	18 – 18
90109–06577	30 – 10
90109–06898	1 – 15
90109–06899	1 – 24
90109–068B2	23 – 28
90109–085G6	31 – 17
	31 – 30
90110–05806	23 – 17
90110–05809	42 – 30
90110–06161	4 – 13
	4 – 15
	12 – 5
90110–06182	15 – 11
90110–06870	1 – 11
90110–06882	10 – 11
90110–08071	31 – 39
	31 – 47
90111–05003	19 – 33
	19 – 39
	19 – 44
	33 – 21
	33 – 25
90111–05018	18 – 28
90111–05021	18 – 25
90111–06013	31 – 16
90111–06117	34 – 36
	34 – 42
	40 – 2
90111–06119	20 – 13
90111–06121	32 – 20
90111–06137	18 – 8
90111–06152	9 – 30
90111–06802	9 – 8
90111–06847	9 – 13
	18 – 9
90111–08087	26 – 2
	28 – 2
90116–10065	27 – 14
90119–06810	19 – 8
	19 – 16
	34 – 4
	34 – 14
90119–06M17	23 – 27
90123–08083	41 – 18
90149–05029	25 – 9
	27 – 20
90149–10044	26 – 13
90150–05023	33 – 17

PART NO.	REF. NO.
90151–03005	41 – 17
90159–06054	24 – 13
90160–04009	43 – 21
90160–05810	19 – 36
90170–06023	16 – 15
90170–18221	13 – 11
90176–06065	30 – 27
90179–05849	33 – 2
90179–07652	2 – 4
90179–08316	41 – 19
90179–10805	17 – 13
90179–20013	14 – 33
90179–25615	21 – 3
90183–05076	18 – 19
90183–050A7	18 – 26
	19 – 3
	19 – 11
	34 – 8
	34 – 16
90183–05807	19 – 2
	19 – 10
	33 – 10
	34 – 26
	34 – 31
	34 – 37
	34 – 43
	39 – 9
	40 – 5
90183–05M02	34 – 38
	34 – 44
90183–06011	9 – 20
90183–06818	9 – 9
	17 – 20
90201–04028	43 – 22
90201–04804	40 – 14
90201–05036	39 – 6
90201–05043	43 – 31
90201–05827	38 – 8
90201–06072	6 – 14
90201–06088	9 – 19
90201–06380	34 – 6
90201–08083	32 – 17
90201–08612	9 – 24
90201–087F0	9 – 26
90201–10021	16 – 20
	31 – 26
90201–10118	30 – 20
	30 – 30

PART NO.	REF. NO.
90201–10118	30 – 33
	30 – 36
	32 – 24
	32 – 27
90201–10119	7 – 6
90201–10843	13 – 16
90201–10845	1 – 10
90201–10848	2 – 9
	35 – 5
90201–127E1	16 – 7
90201–16812	2 – 19
90201–17809	27 – 25
90201–20023	14 – 32
90201–20276	14 – 25
90201–22013	13 – 12
90202–05088	33 – 18
90202–26142	21 – 4
90206–14001	16 – 19
90209–25011	14 – 15
90214–22008	14 – 3
	14 – 20
90215–18800	13 – 10
90240–08124	32 – 16
90240–08145	31 – 13
	31 – 22
	31 – 37
	31 – 45
90269–05005	39 – 11
90269–05008	17 – 31
	23 – 49
90269–06816	18 – 22
	18 – 37
	19 – 7
	19 – 15
	19 – 19
	19 – 22
	23 – 29
	23 – 60
	30 – 25
	33 – 20
	33 – 24
	34 – 55
	34 – 58
90269–07007	17 – 32
90280–05013	35 – 6
90282–04036	2 – 17
90338–05010	29 – 4
	29 – 8

PART NO.	REF. NO.
90338–05010	33 – 36
90338–06018	19 – 38
	19 – 43
90338–09012	30 – 14
	41 – 21
90338–16262	10 – 2
90338–23801	17 – 15
90340–12808	7 – 14
90340–18002	1 – 5
90340–32819	11 – 5
90387–05042	40 – 16
90387–06131	33 – 35
90387–06242	20 – 12
90387–064W3	6 – 15
90387–066J9	18 – 31
90387–067V1	40 – 3
90387–06857	19 – 26
90387–06899	18 – 4
	18 – 5
	19 – 5
	19 – 13
	23 – 22
	34 – 3
	34 – 13
	34 – 35
	34 – 41
90387–068L9	18 – 32
90387–068M3	23 – 8
90387–068N4	9 – 18
90387–068S8	23 – 13
90387–06M60	44 – 5
90387–07819	17 – 18
90387–087L0	9 – 12
	9 – 29
90387–08813	17 – 28
	31 – 49
90387–10010	31 – 6
90387–17810	27 – 2
90387–20814	14 – 24
90388–10816	17 – 7
90401–10812	30 – 19
	30 – 29
	30 – 32
	30 – 35
	32 – 23
	32 – 26
90401–20008	7 – 12
90413–06031	8 – 23

PART NO.	REF. NO.
90430–06014	4 – 8
	5 – 16
	10 – 12
90430–08119	1 – 7
90430–08143	11 – 4
90430–10804	43 – 7
90445–217G3	31 – 8
90450–28001	6 – 7
90450–55804	8 – 4
90462–08225	11 – 24
90462–08806	11 – 20
90462–08810	7 – 18
90462–08812	11 – 19
90464–08009	41 – 23
	42 – 33
90464–10008	23 – 48
90464–10800	44 – 21
90464–12013	44 – 14
90464–12015	17 – 22
90464–13227	41 – 22
90464–14803	44 – 20
	44 – 22
90464–15014	23 – 51
90464–16006	18 – 15
	38 – 10
90464–16012	23 – 44
90464–22800	42 – 23
	44 – 12
90464–26001	42 – 32
90464–30001	41 – 8
90464–30009	17 – 21
	32 – 30
90464–36005	41 – 2
90464–36800	42 – 21
90464–70800	42 – 22
	42 – 24
90467–08003	19 – 31
90467–09006	23 – 46
	23 – 54
	23 – 63
90467–090A2	8 – 24
90467–11009	23 – 62
90467–110A3	8 – 38
90467–12052	8 – 43
90467–12085	32 – 14
90467–13802	8 – 42
	8 – 45
90467–15012	23 – 42
90467–16800	1 – 36
90467–16801	1 – 33
	1 – 35
90467–250A1	6 – 6
90480–01559	23 – 23
90480–01806	23 – 19
90480–01821	34 – 27
	34 – 32
90480–10003	40 – 6
90480–11009	40 – 15
90480–12581	9 – 11
	9 – 28
90480–12808	18 – 6
	18 – 7
	19 – 4
	19 – 12
	23 – 21
	34 – 2
	34 – 12
	34 – 34
	34 – 40
90480–13001	40 – 4
90480–13398	17 – 17
	33 – 5
90480–14229	38 – 6
	39 – 5
	44 – 6
90480–15807	23 – 12
90480–15808	6 – 16
90480–18813	23 – 7
90501–06022	15 – 3
90501–080A2	15 – 8
90501–12743	31 – 34
	31 – 42
90501–22800	2 – 20
90506–23812	31 – 4
90506–26807	31 – 27
90508–18136	13 – 18
90508–183B9	31 – 12
	31 – 21
90508–29806	16 – 5
90520–02843	23 – 4
90520–03841	23 – 26
90520–07808	33 – 6
	33 – 11
90520–10850	19 – 41
	19 – 46
90520–20825	39 – 4
90520–30805	19 – 40
	19 – 45
90560–06244	19 – 34
91312–05008	42 – 18
91312–05010	23 – 18
	23 – 38
	29 – 19
91312–05012	11 – 2
91312–06010	5 – 13
91312–06025	11 – 15
91312–06030	35 – 3
91312–10040	22 – 40
91317–06012	44 – 17
91317–06016	29 – 3
	29 – 7
91317–06020	29 – 15
91317–06030	33 – 34
91317–08020	29 – 2
	29 – 6
91317–08030	21 – 8
91317–10020	17 – 25
91317–10045	17 – 26
91317–10060	17 – 9
91332–06016	8 – 3
	43 – 11
91332–06020	1 – 23
	4 – 10
91332–06030	7 – 8
91401–20012	32 – 18
91401–25015	31 – 14
	31 – 23
	31 – 38
	31 – 46
92012–06016	44 – 19
92012–08030	32 – 19
92014–08012	11 – 3
92902–08600	13 – 20
	27 – 28
92902–10200	17 – 10
92907–10600	17 – 27
93101–20802	14 – 11
	14 – 27
93102–12891	16 – 10
93102–15801	5 – 5
93102–35803	14 – 30
93106–23002	27 – 4
93106–26815	25 – 3
93106–38046	27 – 8
93210–068F7	10 – 14
93210–108H5	41 – 14
93210–12803	10 – 3
93210–15566	43 – 10
93210–15620	32 – 7
93210–16716	1 – 29
93210–21801	43 – 4
93210–27807	5 – 20
93210–32816	11 – 6
93210–39802	8 – 2
93306–20314	27 – 3
93306–255Y9	14 – 8
93306–302X4	25 – 4
93306–30450	27 – 7
93311–420Y3	14 – 10
	14 – 26
93315–21570	5 – 4
93317–11096	5 – 3
93317–11295	16 – 9
93320–32403	20 – 5
93399–99932	22 – 39
93399–999Y3	21 – 1
93440–24200	14 – 4
	14 – 21
93440–28184	14 – 16
93440–52009	14 – 9
93450–16068	2 – 14
93501–04830	31 – 35
	31 – 43
93605–10090	2 – 21
93900–00828	25 – 6
	27 – 17
94111–17812	25 – 5
94114–17814	27 – 16
94568–H3112	27 – 31
94568–K0118	4 – 5
94700–00436	1 – 12
95022–06008	4 – 7
95022–06010	38 – 11
	44 – 3
95022–06012	24 – 4
	34 – 46
95022–06014	17 – 19
95022–06020	6 – 3
	30 – 17
	30 – 21
	42 – 4
95022–06025	5 – 17
95022–06025	7 – 17
	11 – 9
	11 – 12
	11 – 18
	11 – 23
	36 – 7
	44 – 4
95022–06050	11 – 13
95022–08012	1 – 6
95022–08014	23 – 15
95027–06010	9 – 3
95027–06012	30 – 38
	30 – 39
	44 – 8
	44 – 10
95027–06016	23 – 59
	44 – 13
95027–06025	30 – 13
95027–08012	23 – 52
95027–08035	9 – 17
95302–06600	16 – 16
95302–08600	27 – 29
95602–05100	43 – 30
95602–06100	30 – 9
	41 – 15
95602–06200	18 – 33
95602–10200	27 – 15
	31 – 7
95602–12100	20 – 10
	20 – 16
95602–14200	20 – 6
	25 – 13
95602–16200	27 – 24
95607–08200	9 – 31
95612–08625	1 – 8
95702–05500	18 – 14
95702–06500	18 – 10
	34 – 5
95707–06500	24 – 9
95707–08500	9 – 22
95802–06010	31 – 29
95812–06012	30 – 15
95812–06035	10 – 8
95812–06045	10 – 9
95812–06065	10 – 10
95812–08035	33 – 28
95817–06012	23 – 10
95817–08030	9 – 25
95817–10025	31 – 3
95827–06025	6 – 13
95D02–06016	43 – 15
95D02–06025	43 – 17
95D02–08012	43 – 26
95D07–06016	43 – 28
95D32–06010	8 – 40
95D37–06014	32 – 29
97012–06020	16 – 21
97022–06030	23 – 9
	23 – 14
97507–06525	41 – 20
97602–04212	30 – 12
97607–04230	41 – 7
97702–50016	24 – 14
	33 – 4
	34 – 7
	34 – 15
	34 – 20
	34 – 22
	34 – 25
	34 – 30
	34 – 54
	34 – 57
	38 – 7
	39 – 3
	39 – 7
	39 – 10
97702–50025	8 – 32
97707–30020	38 – 4
97707–40020	40 – 13
97707–50016	18 – 27
	19 – 18
	19 – 21
	19 – 24
	34 – 48
	34 – 50
	34 – 52
98502–05016	43 – 5
98502–06012	8 – 9
98507–04025	41 – 4
98507–04030	41 – 6
98902–05020	8 – 35
99002–07600	13 – 21
99009–08400	5 – 11
99009–10400	7 – 5
	13 – 17
99009–12400	16 – 6

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
99009–15500	7 – 2										
99530–08012	7 – 7										
	11 – 8										
	11 – 11										
99530–10014	10 – 5										
99530–14016	1 – 14										
	1 – 30										